

# TECHNICAL & SERVICE MANUAL

<Outdoor unit>  
[Model name]

PUMY-P60NKMU1

[Service Ref.]

**PUMY-P60NKMU1**


Note:

- This service manual describes technical data of the outdoor units only.

Salt proof model

PUMY-P60NKMU1-BS

**PUMY-P60NKMU1-BS**



Model name  
indication

OUTDOOR UNIT

## CONTENTS

1. SAFETY PRECAUTION .....	2
2. OVERVIEW OF UNITS .....	5
3. SPECIFICATIONS .....	10
4. DATA .....	11
5. OUTLINES AND DIMENSIONS .....	20
6. WIRING DIAGRAM .....	21
7. NECESSARY CONDITIONS FOR SYSTEM CONSTRUCTION .....	22
8. TROUBLESHOOTING .....	32
9. ELECTRICAL WIRING .....	107
10. REFRIGERANT PIPING TASKS .....	112
11. DISASSEMBLY PROCEDURE .....	116

**PARTS CATALOG (OCB613)**

## 1-1. CAUTIONS RELATED TO NEW REFRIGERANT

## Cautions for units utilizing refrigerant R410A

**Use new refrigerant pipes.**

Avoid using thin pipes.

**Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc, which are hazard to refrigerant cycle. In addition, use pipes with specified thickness.**

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

**Store the piping indoors, and both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.**

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

**Charge refrigerant from liquid phase of gas cylinder.**

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

**Do not use refrigerant other than R410A.**

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

**Use a vacuum pump with a reverse flow check valve.**

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

**Use the following tools specifically designed for use with R410A refrigerant.**

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

**Handle tools with care.**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**Do not use a charging cylinder.**

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

**Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.**

**Use the specified refrigerant only.**

**Never use any refrigerant other than that specified.**

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.


## [1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) If moisture or foreign matter might have entered the refrigerant piping during service, ensure to remove them.

## [2] Additional refrigerant charge

### When charging directly from cylinder

- (1) Check that cylinder for R410A on the market is a syphon type.
- (2) Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



## [3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	· Only for R410A · Use the existing fitting specifications. (UNF1/2) · Use high-tension side pressure of 768.7 PSI [5.3 MPa.G] or over.
②	Charge hose	· Only for R410A · Use pressure performance of 738.2 PSI [5.09MPa.G] or over.
③	Electronic scale	—
④	Gas leak detector	· Use the detector for R134a, R407C or R410A.
⑤	Adaptor for reverse flow check	· Attach on vacuum pump.
⑥	Refrigerant charge base	—
⑦	Refrigerant cylinder	· Only for R410A · Top of cylinder (Pink) · Cylinder with syphon
⑧	Refrigerant recovery equipment	—

## 1-2. PRECAUTIONS FOR SALT PROOF TYPE "-BS" MODEL

Although "-BS" model has been designed to be resistant to salt damage, observe the following precautions to maintain the performance of the unit.

- (1) Avoid installing the unit in a location where it will be exposed directly to seawater or sea breeze.
- (2) If the cover panel may become covered with salt, be sure to install the unit in a location where the salt will be washed away by rainwater. (If a sunshade is installed, rainwater may not clean the panel.)
- (3) To ensure that water does not collect in the base of the outdoor unit, make sure that the base is level, not at angle. Water collecting in the base of the outdoor unit could cause rust.
- (4) If the unit is installed in a coastal area, clean the unit with water regularly to remove any salt build-up.
- (5) If the unit is damaged during installation or maintenance, be sure to repair it.
- (6) Be sure to check the condition of the unit regularly.
- (7) Be sure to install the unit in a location with good drainage.

## Cautions for refrigerant piping work

New refrigerant R410A is adopted for replacement inverter series. Although the refrigerant piping work for R410A is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R410A is 1.6 times higher than that of R22, their sizes of flared sections and flare nuts are different.

### ① Thickness of pipes

Because the working pressure of R410A is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 7/256 in [0.7 mm] or below.)



Diagram below: Piping diameter and thickness

Nominal dimensions (in)	Outside diameter (mm)	Thickness : in [mm]	
		R410A	R22
1/4	6.35	1/32 [0.8]	1/32 [0.8]
3/8	9.52	1/32 [0.8]	1/32 [0.8]
1/2	12.70	1/32 [0.8]	1/32 [0.8]
5/8	15.88	5/128 [1.0]	5/128 [1.0]
3/4	19.05	—	5/128 [1.0]

### ② Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R410A is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants. Therefore, to enhance airtightness and intensity, flare cutting dimension of copper pipe for R410A has been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R410A also has partly been changed to increase intensity as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R410A below. For 1/2 and 5/8 inch, the dimension B changes.

Use torque wrench corresponding to each dimension.



Flare cutting dimensions

Unit : in [mm]

Nominal dimensions (in)	Outside diameter (mm)	Dimension A ( $\begin{smallmatrix} +0 \\ -0.4 \end{smallmatrix}$ )	
		R410A	R22
1/4	6.35	11/32-23/64 [ 9.1]	9.0
3/8	9.52	1/2-33/64 [13.2]	13.0
1/2	12.70	41/64-21/32 [16.6]	16.2
5/8	15.88	49/64-25/32 [19.7]	19.4
3/4	19.05	—	23.3

Flare nut dimensions

Unit: in [mm]

Nominal dimensions (in)	Outside diameter (mm)	Dimension B	
		R410A	R22
1/4	6.35	43/64 [17.0]	17.0
3/8	9.52	7/8 [22.0]	22.0
1/2	12.70	1-3/64 [26.0]	24.0
5/8	15.88	1-9/64 [29.0]	27.0
3/4	19.05	—	36.0

### ③ Tools for R410A (The following table shows whether conventional tools can be used or not.)

Tools and materials	Use	R410A tools	Can R22 tools be used?	Can R407C tools be used?
Gauge manifold	Air purge, refrigerant charge	Tool exclusive for R410A	×	×
Charge hose	and operation check	Tool exclusive for R410A	×	×
Gas leak detector	Gas leak check	Tool for HFC refrigerant	×	○
Refrigerant recovery equipment	Refrigerant recovery	Tool exclusive for R410A	×	×
Refrigerant cylinder	Refrigerant charge	Tool exclusive for R410A	×	×
Applied oil	Apply to flared section	Ester oil, ether oil and alkylbenzene oil (minimum amount)	×	Ester oil, ether oil: ○ Alkylbenzene oil: minimum amount
Safety charger	Prevent compressor malfunction when charging refrigerant by spraying liquid refrigerant	Tool exclusive for R410A	×	×
Charge valve	Prevent gas from blowing out when detaching charge hose	Tool exclusive for R410A	×	×
Vacuum pump	Vacuum drying and air purge	Tools for other refrigerants can be used if equipped with adpater for reverse flow check	△ (Usable if equipped with adpater for reverse flow)	△ (Usable if equipped with adpater for reverse flow)
Flare tool	Flaring work of piping	Tools for other refrigerants can be used by adjusting flaring dimension	△ (Usable by adjusting flaring dimension)	△ (Usable by adjusting flaring dimension)
Bender	Bend the pipes	Tools for other refrigerants can be used	○	○
Pipe cutter	Cut the pipes	Tools for other refrigerants can be used	○	○
Welder and nitrogen gas cylinder	Weld the pipes	Tools for other refrigerants can be used	○	○
Refrigerant charging scale	Refrigerant charge	Tools for other refrigerants can be used	○	○
Vacuum gauge or thermistor vacuum gauge and vacuum valve	Check the degree of vacuum. (Vacuum valve prevents back flow of oil and refrigerant to thermistor vacuum gauge)	Tools for other refrigerants can be used	○	○
Charging cylinder	Refrigerant charge	Tool exclusive for R410A	×	—

× : Prepare a new tool. (Use the new tool as the tool exclusive for R410A.)

△ : Tools for other refrigerants can be used under certain conditions.


○ : Tools for other refrigerants can be used.

### 2-1. Auxiliary HEATING ON/OFF CONTROL SET-UP

(1) Auxiliary heating operation controls another heat source that depends on the main system's operations, which means the interlock operation shown in "b)" will be possible.

a) Indoor unit must be R410A UL model for this function to operate.

b) Different Indoor unit applications that can be applied:



(2) Outdoor unit DIPSW5-4 for auxiliary heating control:

Set DIPSW5-4 when power is turned off at unit.

**OFF:** Disable auxiliary Heating Function (Initial setting)

**ON :** Enable auxiliary Heating Function

(3) Determine required indoor fans speed during defrost mode:

To set the fan speed, see the chapter referring to heater control in the indoor unit's Technical & Service Manual.

**(4) Determine fan airflow setting during indoor thermo-OFF conditions:**


- a) These settings are done within Indoor DIPSW1-7 and DIPSW1-8, see chart below for options.  
b) Recommended SW1-7 OFF and SW1-8 ON will determine airflow based on "Setting on the remote controller".

Auxiliary heating signal		Fan speed setting	Fan speed setting
Thermo condition		OFF	ON
SW1-7	SW1-8		
OFF	OFF	Very low	Setting on remote controller
ON	OFF	Low	
OFF	ON	Setting on remote controller	
ON	ON	Stopped	

**(5) Setting outdoor unit and auxiliary heat switch over temperatures.**

When the DIPSW 5-4 is set to "ON", the outdoor unit and the contact output operates as shown below.

- a) Outdoor default setting and operations are shown below:



When the set temperature ranges overlap, the previously set pattern (1,2 or 3) has a priority.


The stage 1 has the highest priority, 2 the second and then 3.

- b) Based on above chart listed the sequence of operation on "On ambient decrease"
- ( Stage 1 : (TH7 = > 10°C) : the outdoor unit runs in HP mode.
  - ( Stage 2 : (TH7 = 10°C to -25°C) : the outdoor unit runs in HP mode with auxiliary heating.
  - ( Stage 3 : (TH7 = < -25°C) : Auxiliary heating only (Outdoor unit is OFF).
- c) Based on above chart listed the sequence of operation on "On ambient increase"
- ( Stage 3 : (TH7 = < 0°C) : Auxiliary heating only (Outdoor unit is OFF).
  - ( Stage 2 : (TH7 = > 0°C to 20°C) : Auxiliary heating with outdoor unit in HP mode.
  - ( Stage 1 : (TH7 = > 20°C) : Outdoor unit in HP mode only.

## (6) Locally procured wiring

A basic connection method is shown.

(i.e. interlocked operation with the electric heater with the fan speed setting on high)



For relay X use the specifications given below operation coil

Rated voltage : 12VDC

Power consumption : 0.9W or less

\*Use the diode that is recommended by the relay manufacturer at both ends of the relay coil.

The length of the electrical wiring for the PAC-YU24HT is 2 meters (6-1/2 ft)


To extend this length, use sheathed 2-core cable.

Control cable type : CVV, CVS, CPEV or equivalent.

Cable size : 0.5 mm<sup>2</sup> to 1.25 mm<sup>2</sup> (AWG22 to AWG16)

Do not extend the cable more than 10 meters (32ft).

Recommended circuit




## 2-2. UNIT CONSTRUCTION

Outdoor unit		7HP
		PUMY-P60NKMU1(-BS)
Applicable indoor unit	Capacity	Type 06 to Type 72
	Number of units	1 to 12 unit
	Total system wide capacity	50 to 130% of outdoor unit capacity

	CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E
Branching pipe components	Branch header (2 branches)	Branch header (4 branches)	Branch header (8 branches)

Model	Cassette Ceiling				Ceiling Concealed				Wall Mounted			Ceiling Suspended	Floor standing		Multi-position air handling unit
	4-way flow			1-way flow	PEFY-P				PKFY-P			PCFY-P	Exposed	Concealed	
	PLFY-EP	PLFY-P	PLFY-P	PMFY-P	NMAU	NMSU-E	NHMU-E	NMHSU-E	NBMU-E	NHMU-E	NKMU-E	NKMU-E	PFFY-P	PFFY-P	PVFY-P
Capacity	NEMU-E	NEMU-E	NCMU-E	NBMU-E	NMAU	NMSU-E	NHMU-E	NMHSU-E	NBMU-E	NHMU-E	NKMU-E	NKMU-E	NEMU-E	NRMU-E	NAMU-E
06	—	—	—	○	○	○	—	—	○	—	—	—	○	○	—
08	—	○	○	○	○	○	—	—	—	○	—	—	○	○	—
12	○	○	○	○	○	○	—	—	—	○	—	—	○	○	○
15	○	○	○	○	○	○	○	—	—	○	—	○	○	○	—
18	○	○	—	—	○	○	○	—	—	○	—	—	○	○	○
24	○	○	—	—	○	○	○	—	—	—	○	○	○	○	○
27	—	—	—	—	○	—	○	—	—	—	—	—	—	—	—
30	○	○	—	—	○	—	○	—	—	—	○	○	—	—	○
36	○	○	—	—	○	—	○	—	—	—	—	○	—	—	○
48	○	○	—	—	○	—	○	—	—	—	—	—	—	—	○
54	—	—	—	—	○	—	○	—	—	—	—	—	—	—	○
72	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—



Decorative panel

—: Not connectable  
○: Connectable

Remote controller	Name	M-NET remote controller	MA remote controller
	Model number	PAR-F27MEA-E PAR-U01MEDU	PAR-21MAA, PAR-30/31/32MAA
	Functions	• A handy remote controller for use in conjunction with the Melans centralized management system. • Addresses must be set.	• Addresses setting is not necessary.



## 2-3. UNIT SPECIFICATIONS

### (1) Outdoor Unit


Service Ref.		PUMY-P60NKMU1(-BS)
Capacity	Cooling (kBtu/h)	60.0
	Heating (kBtu/h)	66.0
Compressor (kW)		4.1

Cooling/Heating capacity indicates the maximum value at operation under the following condition.


Cooling	Indoor	D.B. 80°F/W.B. 67°F: [D.B. 26.7°C/W.B. 19.4°C]
	Outdoor	D.B. 95°F/W.B. 75°F: [D.B. 35°C/W.B. 23.9°C]
Heating	Indoor	D.B. D.B. 70°F/W.B. 60°F: [D.B. 21.1°C/W.B. 15.6°C]
	Outdoor	D.B. 47°F/W.B. 43°F: [D.B. 8.3°C/W.B. 6.1°C]

### (2) Method for identifying MULTI-S model

#### ■ Indoor unit < When using Model 80 >



#### ■ Outdoor unit <When using model 125 >



### (3) Operating temperature range

	Cooling	Heating
Indoor-side intake air temperature	59 to 75°F [W.B. 15 to 24°C]	59 to 81°F [D.B. 15 to 27°C]
Outdoor-side intake air temperature	23 to 115°F [D.B. -5 to 46°C]*1*2	-13 to 59°F [W.B. -25 to 15°C]

Notes: D.B. : Dry Bulb Temperature  
W.B. : Wet Bulb Temperature

\*1 50 to 115 °F [10 to 46°C] D.B. : When connecting PKFY-P06NBMU, PKFY-P08NHMU type indoor unit.

\*2 5 to 115°F [-15 to 46°C] D.B.: When using an optional air protect guide [PAC-SH95AG-E].

However, this condition does not apply to the indoor units listed in \*1.

Model			PUMY-P60NKMU1(-BS)
Power source			208/230 V AC 60 Hz
Cooling (Nominal)	Capacity	BTU/h*1	60,000
	Power input	kW	4,680
	Current input 208V / 230V	A	22.8 / 20.6
	EER	BTU/h	12.8
Temp. range of cooling	Indoor temp.	W.B.	59 to 75°F [15 to 24°C]
	Outdoor temp.	D.B.	23 to 115°F [-5 to 46°C] *3*4
Heating (Nominal)	Capacity	BTU/h*2	66,000
	Power input	kW	5,450
	Current input 208V / 230V	A	26.6 / 24.1
	COP	W/W	3.55
Temp. range of heating	Indoor temp.	D.B.	59 to 81°F [15 to 27°C]
	Outdoor temp.	W.B.	-13 to 59°F [-25 to 15°C]
Breaker size			40A
Max. fuse size			42A
Min. circuit ampacity			36A
Indoor unit connectable	Total capacity		50 to 130% of outdoor unit capacity
	Model/ Quantity	Citymulti	06-72 / 12
Sound pressure level (measured in anechoic room)		dB <A>	58 / 59
Refrigerant piping diameter	Liquid pipe	in (mm)	3/8 (9.52)
	Gas pipe	in (mm)	3/4 (19.05)
FAN *2	Type x Quantity		Propeller Fan x 2
	Air flow rate	m³/min	138
		L/s	2,300
		cfm	4,879
	Control, Driving mechanism		DC control
	Motor output	kW	0.2+0.2
	External static press.		0
Compressor	Type x Quantity		Scroll hermetic compressor x 1
	Manufacture		Mitsubishi Electric Corporation
	Starting method		Inverter
	Capacity control	%	Cooling: 36 to 100 Heating: 22 to 100
	Motor output	kW	4.1
	Case heater	kW	0
	Lubricant		FV50S (2.3 liter)
	External finish		
External dimension HxWxD		mm	1,338 x 1,050 x 330(+25)
		in	52-11/16 x 41-11/32 x 13 (+1)
Protection devices	High pressure protection		High pressure Switch, High pressure Sensor
	Inverter circuit (COMP./FAN)		Overcurrent detection, Overheat detection(Heat sink thermistor)
	Compressor		Compressor thermistor, Overcurrent detection
	Fan motor		Overheating, Voltage protection
Refrigerant	Type x original charge		R410A 5.1kg
	Control		Electronic expansion valve
Net weight		kg (lb)	139 (306)
Heat exchanger			Cross Fin and Copper tube
HIC circuit (HIC: Heat Inter-Changer)			HIC circuit
Defrosting method			Reversed refrigerant circuit
Drawing	External		BK01V261
	Wiring		BH78B813
Standard attachment	Document		Installation Manual
	Accessory		Grounded lead wire x2, conduit plate
Optional parts			Joint: CMY-Y62-G-E Header: CMY-Y64/68-G-E
Remarks			
*1 Nominal cooling conditions		*2 Nominal heating conditions	
Indoor : 80.0°F D.B./67.0°F W.B. [26.7°C D.B. /19.4°C W.B.]		70.0°F D.B./60.0°F W.B. [21.1°C D.B./15.6°C W.B.]	
Outdoor : 95.0°F D.B./75.0°F W.B.[35.0°C D.B. /23.9°C W.B.]		47.0°F D.B./43.0°F W.B. [8.3°C D.B./6.1°C W.B.]	
Pipe length : 25 ft [7.6 m]		25 ft [7.6 m]	
Level difference : 0 ft [0 m]		0 ft [0 m]	
*3 50 to 115°F [10 to 46°C] D.B. : When connecting PKFY-P06NBMU and PKFY-P08NHMU type indoor unit.			
*4 5 to 115°F [-15 to 46°C] D.B.: When using an optional air protect guide [PAC-SH95AG-E]. However, this condition does not apply to the indoor units listed in *3.			
Note : Due to continuing improvement, above specifications may be subject to change without notice.			
			Unit converter
			kcal/h = kW × 860 BTU/h = kW × 3,412 cfm = m³/min x 35.31 lb = kg/0.4536
			Above specification data is subject to rounding variation.

## 4-1. SELECTION OF COOLING/HEATING UNITS

### <Cooling>

Design Condition	
Outdoor Design Dry Bulb Temperature	98.6°F (37.0°C)
Total Cooling Load	54.0 kBTU/h
Room1	
Indoor Design Dry Bulb Temperature	80.6°F (27.0°C)
Indoor Design Wet Bulb Temperature	68.0°F (20.0°C)
Cooling Load	26.0 kBTU/h
Room2	
Indoor Design Dry Bulb Temperature	75.2°F (24.0°C)
Indoor Design Wet Bulb Temperature	66.2°F (19.0°C)
Cooling Load	28.0 kBTU/h
<Other>	
Indoor/Outdoor Equivalent Piping Length	100 ft

### Capacity of indoor unit

Model Number for indoor unit	Model 06	Model 08	Model 12	Model 15	Model 18	Model 24	Model 27	Model 30	Model 36	Model 48	Model 54	Model 72
Model Capacity	6.0	8.0	12.0	15.0	18.0	24.0	27.0	30.0	36.0	48.0	54.0	72.0

### 1. Cooling Calculation

#### (1) Temporary Selection of Indoor Units

Room1

PEFY-P27

27.0 kBTU/h (Rated)

Room2

PEFY-P30

30.0 kBTU/h (Rated)

#### (2) Total Indoor Units Capacity

P27 + P30 = P57

#### (3) Selection of Outdoor Unit

The P60 outdoor unit is selected as total indoor units capacity is P57

PUMY-P60

60.0 kBTU/h

#### (4) Total Indoor Units Capacity Correction Calculation

Room1

Indoor Design Wet Bulb Temperature Correction (68.0°F) 1.02 (Refer to Figure 1)

Room2

Indoor Design Wet Bulb Temperature Correction (66.2°F) 0.95 (Refer to Figure 1)

Total Indoor Units Capacity (CTi)

$$\begin{aligned}
 CT_i &= \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction}) \\
 &= 27.0 \times 1.02 + 30.0 \times 0.95 \\
 &= 56.0 \text{ kBTU/h}
 \end{aligned}$$

#### (5) Outdoor Unit Correction Calculation

Outdoor Design Dry Bulb Temperature Correction (98.6°F) 0.98 (Refer to Figure 2)

Piping Length Correction (100 ft) 0.96 (Refer to Figure 3)

Total Outdoor Unit Capacity (CTo)

$$\begin{aligned}
 CT_o &= \text{Outdoor Rating} \times \text{Outdoor Design Temperature Correction} \times \text{Piping Length Correction} \\
 &= 60.0 \times 0.98 \times 0.96 \\
 &= 56.4 \text{ kBTU/h}
 \end{aligned}$$

#### (6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

$CT_i = 56.0 < CT_o = 56.4$ , thus, select  $CT_i$ .

$CT_x = CT_i = 56.0 \text{ kBTU/h}$

#### (7) Comparison with Essential Load

Against the essential load 54.0 kBTU/h, the maximum system capacity is 56.0 kBTU/h: Proper outdoor units have been selected.

#### (8) Calculation of Maximum Indoor Unit Capacity of Each Room

$CT_x = CT_i$ , thus, calculate by the calculation below

Room1

$$\begin{aligned}
 &\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction} \\
 &= 27.0 \times 1.02 \\
 &= 27.5 \text{ kBTU/h} \quad \text{OK: fulfills the load 26.0 kBTU/h}
 \end{aligned}$$

Room2

$$\begin{aligned}
 &\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction} \\
 &= 30.0 \times 0.95 \\
 &= 28.5 \text{ kBTU/h} \quad \text{OK: fulfills the load 28.0 kBTU/h}
 \end{aligned}$$

Go on to the heating trial calculation since the selected units fulfill the cooling loads of Room 1, 2.




Figure 1 Indoor unit temperature correction  
To be used to correct indoor unit only




Figure 2 Outdoor unit temperature correction  
To be used to correct outdoor unit only




Figure 3 Correction of refrigerant piping length

## <Heating>

Design Condition	
Outdoor Design Wet Bulb Temperature	35.6°F (2.0°C)
Total Heating Load	55.0 kBTU/h
Room1	
Indoor Design Dry Bulb Temperature	69.8°F (21.0°C)
Heating Load	26.5 kBTU/h
Room2	
Indoor Design Dry Bulb Temperature	73.4°F (23.0°C)
Heating Load	28.5 kBTU/h
<Other>	
Indoor/Outdoor Equivalent Piping Length	100 ft

### Capacity of indoor unit

Model Number for indoor unit	Model 06	Model 08	Model 12	Model 15	Model 18	Model 24	Model 27	Model 30	Model 36	Model 48	Model 54	Model 72
Model Capacity	6.7	9.0	13.5	17.0	20.0	27.0	30.0	34.0	40.0	54.0	60.0	80.0

## 2. Heating Calculation

### (1) Temporary Selection of Indoor Units

Room1  
PEFY-P27 30.0 kBTU/h (Rated)

Room2  
PEFY-P30 34.0 kBTU/h (Rated)

### (2) Total Indoor Units Capacity

P27 + P30 = P57

### (3) Selection of Outdoor Unit

The P60 outdoor unit is selected as total indoor units capacity is P57

PUMY-P60 66.0 kBTU/h

### (4) Total Indoor Units Capacity Correction Calculation

Room1  
Indoor Design Dry Bulb Temperature Correction (69.8°F) 1.00 (Refer to Figure 4)

Room2  
Indoor Design Dry Bulb Temperature Correction (73.4°F) 0.92 (Refer to Figure 4)

Total Indoor Units Capacity (CTi)

$$CTi = \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction})$$

$$= 30.0 \times 1.00 + 34.0 \times 0.92$$

$$= 61.3 \text{ kBTU/h}$$

### (5) Outdoor Unit Correction Calculation

Outdoor Design Wet Bulb Temperature Correction (35.6°F) 1.0 (Refer to Figure 5)

Piping Length Correction (100 ft) 0.96 (Refer to Figure 6)

Defrost Correction 0.89 (Refer to Table 1)

Total Outdoor Unit Capacity (CTo)

$$CTo = \text{Outdoor Unit Rating} \times \text{Outdoor Design Temperature Correction} \times \text{Piping Length Correction} \times \text{Defrost Correction}$$

$$= 66.0 \times 1.0 \times 0.96 \times 0.89$$

$$= 56.4 \text{ kBTU/h}$$




Figure 4 Indoor unit temperature correction  
To be used to correct indoor unit only




Figure 5 Outdoor unit temperature correction  
To be used to correct outdoor unit only




Figure 6 Correction of refrigerant piping length

Outdoor Intake temperature <W.B. °F (°C)>	43(6)	39(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-20)
Correction factor	1.0	0.98	0.89	0.88	0.89	0.9	0.95	0.95	0.95	0.95	0.95	0.95

### (6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

CTi = 61.3 > CTo = 56.4, thus, select CTo.

CTx = CTo = 56.4 kBTU/h kW

### (7) Comparison with Essential Load

Against the essential load 55.0 kBTU/h, the maximum system capacity is 56.4 kBTU/h: Proper outdoor units have been selected.

### (8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTo, thus, calculate by the calculation below

Room1

$$\text{Maximum Capacity} \times \text{Room1 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction})$$

$$= 56.4 \times (30.0 \times 1.00) / (30.0 \times 1.00 + 34.0 \times 0.92)$$

$$= 27.6 \text{ kBTU/h} \quad \text{OK: fulfills the load 26.5 kBTU/h}$$

Room2

$$\text{Maximum Capacity} \times \text{Room2 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction})$$

$$= 56.4 \times (34.0 \times 0.92) / (30.0 \times 1.00 + 34.0 \times 0.92)$$

$$= 28.8 \text{ kBTU/h} \quad \text{OK: fulfills the load 28.5 kBTU/h}$$

Completed selecting units since the selected units fulfill the heating loads of Room 1, 2.


## 4-2. CORRECTING BY TEMPERATURE

CITY MULTI could have varied capacity at different designing temperature. Using the nominal cooling/heating capacity value and the ratio below, the capacity can be observed at various temperature.


### <Cooling>

		PUMY
		P60
Nominal cooling capacity	BTU/h	60,000
Input	kW	4.68

**Figure 7 Indoor unit temperature correction**  
To be used to correct indoor unit capacity only




**Figure 8 Outdoor unit temperature correction**  
To be used to correct outdoor unit capacity only




# <Heating>

		PUMY
		P60
Nominal heating capacity	BTU/h	66,000
Input	kW	5.45

**Figure 9 Indoor unit temperature correction**  
To be used to correct indoor unit capacity only



**Figure 10 Outdoor unit temperature correction**  
To be used to correct outdoor unit capacity only



### 4-3. STANDARD OPERATION DATA (REFERENCE DATA)


Operation				PUMY-P60NKMU1(-BS)	
Operating conditions	Ambient temperature	Indoor	DB/WB	80°F / 67°F [26.7°C / 19.4°C]	70°F / 60°F [21.1°C / 15.6°C]
		Outdoor		95°F / 75°F [35.0°C / 23.9°C]	47°F / 43°F [8.3°C / 6.1v]
	Indoor unit	No. of connected units	Unit	4	
		No. of units in operation		4	
	Piping	Model	-	15 × 4	
		Main pipe	Ft (m)	9.84 (3)	
		Branch pipe		14.76 (4.5)	
		Total pipe length		68.90 (21)	
	Fan speed		-	Hi	
	Amount of refrigerant		LBS. OZ. (kg)	19LBS. 6OZ. (8.8)	
Outdoor unit	Electric current		A	20.6	24.1
	Voltage		V	230	
	Compressor frequency		Hz	42	52
LEV opening	Indoor unit		Pulse	389	498
Pressure	High pressure/Low pressure		psi[MPa]	342/136 [2.36/0.94]	425/97 [2.93/0.67]
Temp. of each section	Outdoor unit	Discharge	°F[°C]	136.8 [58.2]	154.4 [68.0]
		Heat exchanger outlet		90.0 [32.2]	33.1 [0.6]
		Accumulator inlet		55.4 [13.0]	32.2 [0.1]
		Compressor inlet		57.2 [14.0]	30.9 [-0.6]
	Indoor unit	Lev inlet		80.6 [27.0]	104.0 [40.0]
		Heat exchanger inlet		50.0 [10.0]	141.8 [61.0]



#### 4-4. STANDARD CAPACITY DIAGRAM




Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on "4-1-1. Method for obtaining system cooling and heating capacity".

##### 4-4-1. PUMY-P60NKMU1(-BS) <cooling>





#### 4-4-2. PUMY-P60NKMU1(-BS) <heating>



## 4-5. CORRECTING CAPACITY FOR CHANGES IN THE LENGTH OF REFRIGERANT PIPING

- (1) During cooling, obtain the ratio (and the equivalent piping length) of the outdoor units rated capacity and the total in-use indoor capacity, and find the capacity ratio corresponding to the standard piping length from Figure 11 to 13. Then multiply by the cooling capacity from Figure 7 and 8 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.
- (2) During heating, find the equivalent piping length, and find the capacity ratio corresponding to standard piping length from Figure 12. Then multiply by the heating capacity from Figure 9 and 10 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.

### (1) Capacity Correction Curve

Figure 11 PUMY-P60NKMU1(-BS) <Cooling>





Figure 12 PUMY-P60NKMU1(-BS) <Heating>



### (2) Method for Obtaining the Equivalent Piping Length

Equivalent length for type P60 = (length of piping to farthest indoor unit) + (0.3 × number of bends in the piping) (m)

Length of piping to farthest indoor unit: type P60.....80 m

### 4-5-1. Correction of Heating Capacity for Frost and Defrosting

If heating capacity has been reduced due to frost formation or defrosting, multiply the capacity by the appropriate correction factor from the following table to obtain the actual heating capacity.

#### Correction factor diagram



Outdoor Intake temperature <W.B.°F (°C)>	43(6)	39(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-25)
Correction factor	1.0	0.98	0.89	0.88	0.89	0.9	0.95	0.95	0.95	0.95	0.95	0.95



4-6. NOISE CRITERION CURVES


PUMY-P60NKMU1(-BS)

MODE	SPL(dB)	LINE
COOLING	58	
HEATING	59	




## PUMY-P60NKMU1(-BS)

Unit: mm&lt;inch&gt;



## PUMY-P60NKMU1(-BS)

SYMBOL	NAME
TB1	Terminal Block <Power Supply>
TB3	Terminal Block <Indoor/Outdoor Transmission Line>
TB7	Terminal Block <Centralized Control Transmission Line>
MC	Motor For Compressor
MF1,MF2	Fan Motor
21S4	Solenoid Valve Coil<4-Way Valve>
63H	High Pressure Switch
63HS	High Pressure Sensor
63LS	Low Pressure Sensor
SV1	Solenoid Valve Coil<Bypass Valve>
TH2	Thermistor<Hic Pipe>
TH3	Thermistor<Outdoor Liquid Pipe>
TH4	Thermistor<Compressor>
TH6	Thermistor<Suction Pipe>
TH7	Thermistor<Ambient>
TH8	Thermistor<Heat Sink>
LEV-A,LEV-B	Linear Expansion Valve
DCL	Reactor
P.B.	Power Circuit Board
U/V/W	Connection Terminal<U/V/W-Phase>
LI	Connection Terminal<L-Phase>
NI	Connection Terminal<N-Phase>
DCL1,DCL2	Connection Terminal<Reactor>
IGBT	Power Module
E1,E2,E3,E4	Connection Terminal<Electrical Parts Box>
MULTI.B.	Multi Controller Circuit Board
SW1	Switch<Display Selection>
SW2	Switch<Function Selection>
SW3	Switch<Test Run>
SW4	Switch<Model Selection>
SW5	Switch<Function Selection>
SW6	Switch<Function Selection>
SW7	Switch<Function Selection>
SW8	Switch<Model Selection>
SW9	Switch<Function Selection>
SWU1	Switch<Unit Address Selection, ones digit>
SWU2	Switch<Unit Address Selection, tens digit>
CNS1	Connector <Indoor/Outdoor Transmission Line>
CNS2	Connector<Centralized Control Transmission Line>
SS	Connector<Connection For Option>
CN3D	Connector<Connection For Option>
CN3S	Connector<Connection For Option>
CN3N	Connector<Connection For Option>
CN51	Connector<Connection For Option>
LED1,LED2	LED<Operation Inspection Display>
LED3	LED<Power Supply to Main Microcomputer>
F1,F2	Fuse<UL6.3A250V>
X501~505	Relay
M-NET P.B.	M-NET Power Circuit Board
TB1	Connection Terminal<Electrical Parts Box>



## Cautions when Servicing

- ⚠ **WARNING:** When the main supply is turned off, the voltage [340 V] in the main capacitor will drop to 20 V in approx. 2 minutes (input voltage: 230 V). When servicing, make sure that LED1, LED2 on the outdoor multi controller circuit board goes out, and then wait for at least 1 minute.
- Components other than the outdoor circuit boards may be faulty: Check and take corrective action, referring to the service manual. Do not replace the outdoor circuit boards without checking.

## Précautions pendant l'entretien

- ⚠ **AVERTISSEMENT :** lorsque l'alimentation principale est hors tension, la tension [340 V] dans le condensateur principal chute à 20 V en 2 minutes environ (tension d'entrée : 230 V). Lors de l'entretien, assurez-vous que la diode LED1, LED2 sur la carte de circuit extérieure s'éteint, puis patientez au moins 1 minute.
- Des composants autres que la carte de circuit extérieure peuvent être défectueux : vérifiez et prenez des mesures de correction, en vous reportant au manuel d'entretien. Ne remplacez pas la carte de circuit extérieure sans vérification.

## NOTES:

1. Refer to the wiring diagrams of the indoor units for details on wiring of each indoor unit.
2. Self-diagnosis function  
The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED indication (LED1, LED2) found on the outdoor multi controller circuit board.  
LED indication : Set all contacts of SW1 to OFF.

- During normal operation  
The LED indicates the drive state of outdoor unit.


Bit	1	2	3	4	5	6	7	8
Indication	Compressor operated	52C	21S4	SV1	(SV2)	—	—	Always lit

- When fault requiring inspection has occurred  
The LED alternately indicates the check code and the address of the unit in which the fault has occurred.

[Example]  
When the compressor and SV1 are on during cooling operation.

1	2	3	4	5	6	7	8
8	8	8	8	8	8	8	8


## 7-1. TRANSMISSION SYSTEM SETUP



## 7-2. Special Function Operation and Settings for M-NET Remote Controller

For the detailed procedure of "group settings" and "paired settings", refer to the remote controller's manuals.

## 7-3. REFRIGERANT SYSTEM DIAGRAM PUMY-P60NKMU1(-BS)



Capillary tube for oil separator :  $\phi 2.5 \times \phi 0.8 \times L800$   
 Capillary tube for solenoid valve :  $\phi 4.0 \times \phi 3.0 \times L500$

Refrigerant piping specifications <dimensions of flared connector>

Unit: in <mm>

Capacity	Item	Liquid piping	Gas piping
Indoor unit	P06, P08, P12, P15, P18	1/4 < $\phi 6.35$ >	1/2 < $\phi 12.7$ >
	P24, P30, P36, P48, P54	3/8 < $\phi 9.52$ >	5/8 < $\phi 15.88$ >
	P72	3/8 < $\phi 9.52$ >	3/4 < $\phi 19.05$ >
Outdoor unit	P60	3/8 < $\phi 9.52$ >	3/4 < $\phi 19.05$ >

## 7-4. SYSTEM CONTROL

### 7-4-1. Example for the System

- Example for wiring control cables, wiring method and address setting, permissible lengths, and the prohibited items are listed in the standard system with detailed explanation.




A. Example of a M-NET remote controller system (address setting is necessary.)

Example of wiring control cables		Wiring Method and Address Setting																
<div>1. Standard operation</div> <div></div> <div><ul style="list-style-type: none"><li>1 M-NET remote controller for each M-NET control indoor unit.</li><li>There is no need for setting the 100 position on the M-NET remote controller.</li></ul></div>		<div>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each M-NET control indoor unit (M-IC). Use non-polarized 2-core wire.</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block (TB6) for M-NET the remote controller (M-NET RC).</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>M-NET control indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit (OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor unit plus 50.</td></tr><tr><td>M-NET Remote controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr></tbody></table>		Unit	Range	Setting Method	M-NET control indoor unit (M-IC)	001 to 050	—	Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.	M-NET Remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100			
Unit	Range	Setting Method																
M-NET control indoor unit (M-IC)	001 to 050	—																
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.																
M-NET Remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
<div>2. Operation using 2 M-NET remote controllers</div> <div></div> <div><ul style="list-style-type: none"><li>Using 2 M-NET remote controllers for each M-NET control indoor unit.</li></ul></div>		<div>a. Same as above a</div> <div>b. Same as above b</div> <div>c. Set address switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>M-NET control indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit (OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor units plus 50.</td></tr><tr><td>Main M-NET Remote Controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr><tr><td>Sub M-NET Remote Controller (M-NET RC)</td><td>151 to 200</td><td>Indoor unit address plus 150</td></tr></tbody></table>		Unit	Range	Setting Method	M-NET control indoor unit (M-IC)	001 to 050	—	Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.	Main M-NET Remote Controller (M-NET RC)	101 to 150	Indoor unit address plus 100	Sub M-NET Remote Controller (M-NET RC)	151 to 200	Indoor unit address plus 150
Unit	Range	Setting Method																
M-NET control indoor unit (M-IC)	001 to 050	—																
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.																
Main M-NET Remote Controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
Sub M-NET Remote Controller (M-NET RC)	151 to 200	Indoor unit address plus 150																
<div>3. Group operation</div> <div></div> <div><ul style="list-style-type: none"><li>Multiple M-NET control indoor units operated together by 1 M-NET remote controller</li></ul></div>		<div>a. Same as above a</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the M-IC main unit with the most recent address within the same M-NET control indoor unit (M-IC) group to terminal block (TB6) on the M-NET remote controller.</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>M-IC (Main)</td><td>001 to 050</td><td>Use the smallest address within the same group of M-NET control indoor units.</td></tr><tr><td>M-IC (Sub)</td><td>001 to 050</td><td>Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).</td></tr><tr><td>Outdoor unit</td><td>051 to 100</td><td>Use the smallest address of all the M-NET control indoor units plus 50.</td></tr><tr><td>Main M-NET Remote Controller (M-NET RC)</td><td>101 to 150</td><td>Set at an M-IC (Main) address within the same group plus 100.</td></tr></tbody></table> <div>d. Use the M-NET control indoor unit (M-IC) within the group with the most functions as the M-IC (Main) unit.</div>		Unit	Range	Setting Method	M-IC (Main)	001 to 050	Use the smallest address within the same group of M-NET control indoor units.	M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).	Outdoor unit	051 to 100	Use the smallest address of all the M-NET control indoor units plus 50.	Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
Unit	Range	Setting Method																
M-IC (Main)	001 to 050	Use the smallest address within the same group of M-NET control indoor units.																
M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).																
Outdoor unit	051 to 100	Use the smallest address of all the M-NET control indoor units plus 50.																
Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.																
Combinations of 1 through 3 above are possible.																		



• Name, Symbol and the Maximum Remote controller Units for Connection

Name	Symbol	Maximum units for connection
Outdoor unit	OC	—
M-NET control Indoor unit	M-IC	1 OC unit can be connected to 1 to 10 (P60) M-IC units
M-NET remote controller	M-NET RC	Maximum 2 M-NET RC for 1 indoor unit, Maximum 10 M-NET RC for 1 OC

Permissible Lengths	Prohibited items
<p>Longest transmission cable length AWG 16 [1.25 mm<sup>2</sup>]  <math>L_1 + L_2, L_3 + L_1 \leq 656A [200 m]</math>  M-NET Remote controller cable length  1. If AWB 20 to AWG 16 [0.5 to 1.25 mm<sup>2</sup>]  <math>\ell_1, \ell_2 \leq 33 ft [10 m]</math>  2. If the length exceeds 33 ft [10 m], the exceeding section should be AWG 16 [1.25 mm<sup>2</sup>] and that section should be a value within the total extension length of the transmission cable and maximum transmission cable length. (L3)</p>	<ul style="list-style-type: none"> <li>M-NET remote controller (M-NET RC) and MA remote controller (MA RC) cannot be used together.</li> <li>Do not connect anything with TB15 of M-NET control indoor unit (M-IC).</li> </ul> 
Same as above	 <ul style="list-style-type: none"> <li>① Use the M-NET control indoor unit (M-IC) address plus 150 as the sub M-NET remote controller address. In this case, it should be 152.</li> <li>② 3 or more M-NET remote controllers (M-NET RC) cannot be connected to 1 M-NET control indoor unit.</li> </ul>
Same as above	 <ul style="list-style-type: none"> <li>① The M-NET remote controller address is the M-NET control indoor unit main address plus 100. In this case, it should be 101.</li> </ul>

B. Example of a group operation system with 2 or more outdoor units and a M-NET remote controller.  
(Address settings are necessary.)

Examples of Transmission Cable Wiring

(A) : Group  
 (B) : Group  
 (C) : Group  
 (D) : Shielded Wire  
 (E) : Sub M-NET Remote Controller  
 ( ) : Address example

Wiring Method Address Settings

a. Always use shielded wire when making connections between the outdoor unit (OC) and the M-NET control indoor unit (M-IC), as well for all OC-OC, and IC-IC wiring intervals.

b. Use feed wiring to connect terminals M1 and M2 and the ground terminal on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1 and M2 on the terminal S on the transmission cable terminal block of the M-NET control indoor unit (M-IC).

c. Connect terminals M1 and M2 on the transmission cable terminal block of the M-NET control indoor unit (M-IC) that has the most recent address within the same group to the terminal block on the M-NET remote controller (M-NET RC).

d. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).

e. DO NOT change the jumper connector CN41 on outdoor multi controller circuit board.

f. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit with the earth.


g. Set the address setting switch as follows.

Unit	Range	Setting Method
M-IC (Main)	01 to 50	Use the smallest address within the same group of M-NET control indoor units.
M-IC (Sub)	01 to 50	Use an address, other than the M-IC (Main) in the same group of M-NET control indoor units. This must be in sequence with the M-IC (Main).
Outdoor Unit	51 to 100	Use the smallest address of all the M-NET control indoor units plus 50. The address automatically becomes "100" if it is set as "01-50".
Main M-NET Remote Controller	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
Sub M-NET Remote Controller	151 to 200	Set at an M-IC (Main) address within the same group plus 150.
MA Remote Controller	—	Address setting is not necessary. (Main/sub setting is necessary.)

h. The group setting operations among the multiple M-NET control indoor units is done by the M-NET remote controller (M-NET RC) after the electrical power has been turned on.

• Name, Symbol, and the Maximum Units for Connection




- Permissible Length
- Longest length via outdoor units :  $L_1+L_2+L_3+L_4$ ,  $L_1+L_2+L_3+L_5$ ,  $L_1+L_2+L_6+L_7 \leq 1640$  ft [500 m] (AWG 16 [1.25 mm<sup>2</sup>])
  - Longest transmission cable length :  $L_1$ ,  $L_3+L_4$ ,  $L_3+L_5$ ,  $L_2+L_6$ ,  $L_7 \leq 656$  ft [200 m] (AWG 16 [1.25 mm<sup>2</sup>])
  - M-NET Remote controller cable length :  $\ell_1$ ,  $\ell_2$ ,  $\ell_2+\ell_3$ ,  $\ell_4 \leq 33$  ft [10 m] (AWG 20 to AWG 16 [0.5 to 1.25 mm<sup>2</sup>])
- If the length exceeds 33 ft [10 m], use a AWG 16 [1.25 mm<sup>2</sup>] shielded wire. The length of this section (L<sub>8</sub>) should be included in the calculation of the maximum length and overall length.






- Never connect together the terminal blocks (TB5) for transmission wires for M-NET control indoor units (M-IC) that have been connected to different outdoor units (OC).
- Set all addresses to ensure that they are not overlapped.
- M-NET remote controller and MA remote controller cannot be connected with the M-NET control indoor unit of the same group wiring together.


C. Example of a MA remote controller system (address setting is not necessary.)

NOTE : In the case of same group operation, need to set the address that is only main M-NET control indoor unit.

Example of wiring control cables	Wiring Method and Address Setting
<p>1. Standard operation</p>  <p>• 1 MA remote controller for each indoor unit.</p>	<p>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each M-NET control indoor unit (M-IC). Use non-polarized 2-core wire.</p> <p>b. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each M-NET control indoor unit with the terminal block for the MA remote controller (MA-RC).</p>
<p>2. Operation using two remote controllers</p>  <p>• Using 2 MA remote controllers for each M-NET control indoor unit.</p>	<p>a. The same as above a</p> <p>b. The same as above b</p> <p>c. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 MA remote controllers.</p> <p>· Set either one of the MA remote controllers to "sub remote controller".</p> <p>Refer to the installation manual of MA remote controller.</p>
<p>3. Group operation</p>  <p>• Multiple indoor units operated together by 1 MA remote controller.</p>	<p>a. The same as above a</p> <p>b. The same as above b</p> <p>c. Connect terminals 1 and 2 on transmission cable terminal block (TB15) of each M-NET control indoor unit, which is doing group operation with the terminal block the MA remote controller. Use non-polarized 2-core wire.</p> <p>d. In the case of same group operation, need to set the address that is only main M-NET control indoor unit. Please set the smallest address within number 01-50 of the M-NET control indoor unit with the most functions in the same group.</p>
<p>Combinations of 1 through 3 above are possible.</p>	

Permissible Lengths	Prohibited items
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 656 \text{ ft [200 m]}</math> (AWG 16 [1.25 mm<sup>2</sup>])</p> <p>MA remote controller cable length:  <math>\ell_1, \ell_2 \leq 656 \text{ ft [200 m]}</math> (AWG 22 to AWG 16 [0.3 to 1.25 mm<sup>2</sup>])</p>	<p>The MA remote controller and the M-NET remote controller cannot be used together with the M-NET control indoor unit of the same group.</p>  <p>OC (00)</p> <p>M-IC (00)</p> <p>M-IC (00)</p> <p>M-NET RC (00)</p> <p>MA-RC</p> <p>MA-RC</p>
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 656 \text{ ft [200 m]}</math> (AWG 16 [1.25 mm<sup>2</sup>])</p> <p>MA remote controller cable length:  <math>\ell_3 + \ell_4, \ell_5 \leq 656 \text{ ft [200 m]}</math> (AWG 22 to AWG 16 [0.3 to 1.25 mm<sup>2</sup>])</p>	<p>3 MA remote controllers or more cannot be connected with the M-NET control indoor unit of the same group.</p>  <p>OC (00)</p> <p>M-IC (00)</p> <p>M-IC (00)</p> <p>MA-RC (Main)</p> <p>MA-RC (Main)</p> <p>MA-RC (Sub)</p> <p>MA-RC (Main)</p> <p>MA-RC (Sub)</p>
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 656 \text{ ft [200 m]}</math> (AWG 16 [1.25 mm<sup>2</sup>])</p> <p>MA remote controller cable length:  <math>\ell_7 + \ell_8 \leq 656 \text{ ft [200 m]}</math> (AWG 22 to AWG 16 [0.3 to 1.25 mm<sup>2</sup>])</p>	<p>The second MA remote controller is connected with the terminal block (TB15) for the MA remote controller of the same M-NET control indoor unit (M-IC) as the first MA remote control.</p>  <p>OC (00)</p> <p>M-IC (00)</p> <p>M-IC (00)</p> <p>MA-RC</p> <p>MA-RC</p>

D. Example of a group operation with 2 or more outdoor units and a MA remote controller.  
(Address settings are necessary.)




• Name, Symbol, and the Maximum Units for Connection

Permissible Length

Longest length via outdoor unit (M-NET cable):  $L_1+L_2+L_3+L_4$  and  $L_1+L_2+L_6+L_7 \leq 1640$  ft [500 m] (AWG 16 [1.25 mm<sup>2</sup>] or more)  
 Longest transmission cable length (M-NET cable):  $L_1$  and  $L_3+L_4$  and  $L_2+L_6$  and  $L_7 \leq 656$  ft [200 m] (AWG 16 [1.25 mm<sup>2</sup>] or more)  
 MA Remote controller cable length:  $m_1$  and  $m_1+m_2+m_3$  and  $m_1+m_2+m_3+m_4 \leq 656$  ft [200 m] (AWG 22 to AWG 16 [0.3 to 1.25 mm<sup>2</sup>])

Prohibited items



- (A) : Group  
 (B) : Group  
 (C) : Group  
 (D) : Shielded Wire  
 (E) : Sub MA Remote Controller  
 ( ) : Address example

- Never connect together the terminal blocks (TB5) for transmission wires for M-NET control indoor units (M-IC) that have been connected to different outdoor units (OC).
- M-NET remote controller and MA remote controller cannot be connected with the M-NET control indoor unit of the same group wiring together.

## 8-1. CHECK POINTS FOR TEST RUN

### 8-1-1. Procedures before test run


- (1) Before a test run, make sure that the following work is completed.
  - Installation related :  
Make sure that the panel of cassette type and electrical wiring are done.  
Otherwise electrical functions like auto vane will not operate normally.
  - Piping related :  
Perform leakage test of refrigerant and drain piping.  
Make sure that all joints are perfectly insulated.  
Check stop valves on both liquid and gas side for full open.
  - Electrical wiring related :  
Check ground wire, transmission cable, remote controller cable, and power supply cable for secure connection.  
Make sure that all switch settings of address or adjustments for special specification systems are correctly settled.
- (2) Safety check :  
With the insulation tester of 500 V, inspect the insulation resistance.  
Do not touch the transmission cable and remote controller cable with the tester.  
The resistance should be over 1.0 MΩ. Do not proceed inspection if the resistance is under 1.0 MΩ.  
Inspect between the outdoor unit power supply terminal block and ground first, metallic parts like refrigerant pipes or the electrical box next, then inspect all electrical wiring of outdoor unit, indoor unit, and all linked equipment .
- (3) Before operation :
  - a) Turn the power supply switch of the outdoor unit to on for compressor protection. For a test run, wait at least 12 hours from this point.
  - b) Register control systems into remote controller(s). Never touch the ON/OFF switch of the remote controller(s). Refer to "7-2. Special Function Operation and Settings for M-NET Remote Controller" as for settings. In MA remote controller(s), this registration is unnecessary.
- (4) More than 12 hours later from power supply to the outdoor unit, turn all power switch to on for the test run. Perform test run according to the "Operation procedure" table of the bottom of this page. While test running, make test run reports .

#### 8-1-1-1. Test run for M-NET Remote controller

For the detailed procedure, refer to the remote controller's manuals.





### 8-1-1-2. Test run for wired remote controller <PAR-30MAA> <PAR-31MAA>





- ① Select "Service" from the Main menu, and press the button.



Select "Test run" with the or button, and press the button.



- ② Select "Test run" with the or button, and press the button.



#### Test run operation



Press the button to go through the operation modes in the order of "Cool and Heat".

**Cool mode:** Check the cold air blows out.

**Heat mode:** Check the heat blows out.



Press the button and open the Vane setting screen.



#### Auto vane check\*



Check the auto vane with the buttons.  
Check the operation of the outdoor unit fan, also.



Press the button to return to "Test run operation".



Press the button.



When the test run is completed, the "Test run menu" screen will appear.  
The test run will automatically stop after 2 hours.

\*The function is available only for the model with vanes.

## 8-1-2. Countermeasures for Error During Test Run

- If a problem occurs during test run, a code number will appear on the remote controller (or LED on the outdoor unit), and the air conditioning system will automatically cease operating.

Determine the nature of the abnormality and apply corrective measures.

Check code (2 digits)	Check code (4 digits)	Trouble	Detected Unit			Remarks
			Indoor	Outdoor	Remote Controller	
Ed	0403	Serial communication error		○		Outdoor unit outdoor multi controller circuit board – Power circuit board communication trouble
U2	1102	Compressor temperature trouble		○		Check delay code 1202
UE	1302	High pressure trouble		○		Check delay code 1402
U7	1500	Superheat due to low discharge temperature trouble		○		Check delay code 1600
U2	1501	Refrigerant shortage trouble		○		Check delay code 1601
		Closed valve in cooling mode		○		Check delay code 1501
EF	1508	4-way valve trouble in heating mode		○		Check delay code 1608
PA	2500	Water leakage	○			
P5	2502	Drain over flow protection	○			
P4	2503	Drain sensor trouble	○			
UF	4100	Compressor current interruption (locked compressor)		○		Check delay code 4350
Pb	4114	Fan trouble (indoor)	○			
UP	4210	Compressor overcurrent interruption		○		
U9	4220	Voltage shortage/Overvoltage/PAM error/L1open phase/power synchronization signal error		○		Check delay code 4320
U5	4230	Heat Sink temperature trouble		○		Check delay code 4330
U6	4250	Power module trouble or Overcurrent trouble		○		Check delay code 4350
U8	4400	Fan trouble (Outdoor)		○		Check delay code 4500
U3	5101	Air inlet thermistor (TH21) open/short or Compressor temperature thermistor (TH4) open/short	○	○		Check delay code 1202
U4	5102	Liquid pipe temperature thermistor (TH22) open/short or Suction pipe temperature thermistor (TH6) open/short	○	○		Check delay code 1211
U4	5103	Gas pipe temperature thermistor (TH23) open/short	○			
U4	5105	Outdoor liquid pipe temperature thermistor (TH3) open/short		○		Check delay code 1205
U4	5106	Ambient thermistor (TH7) open/short		○		Check delay code 1221
U4	5109	HIC pipe temperature thermistor (TH2) open/short		○		Check delay code 1222
U4	5110	Heat Sink temperature thermistor (TH8) open/short		○		Check delay code 1214
F5	5201	High pressure sensor (63HS) trouble		○		Check delay code 1402
F3	5202	Low pressure sensor (63LS) trouble		○		Check delay code 1400
UH	5300	Current sensor trouble/Primary current trouble		○		Check delay code 4310
P4	5701	Contact failure of drain float switch	○			
A0	6600	Duplex address error	○	○	○	Only M-NET Remote controller is detected.
A2	6602	Transmission processor hardware error	○	○	○	Only M-NET Remote controller is detected.
A3	6603	Transmission bus BUSY error	○	○	○	Only M-NET Remote controller is detected.
A6	6606	Signal communication error with transmission processor	○	○	○	Only M-NET Remote controller is detected.
A7	6607	No ACK error	○		○	Only M-NET Remote controller is detected.
A8	6608	No response frame error	○		○	Only M-NET Remote controller is detected.
E0/E4	6831	MA communication receive error	○		○	Only MA Remote controller is detected.
E3/E5	6832	MA communication send error	○		○	Only MA Remote controller is detected.
E3/E5	6833	MA communication send error	○		○	Only MA Remote controller is detected.
E0/E4	6834	MA communication receive error	○		○	Only MA Remote controller is detected.
EF	7100	Total capacity error		○		
EF	7101	Capacity code error	○	○		
EF	7102	Connecting unit number error		○		
EF	7105	Address setting error		○		
EF	7130	Incompatible unit combination		○		

### Notes:

- When the outdoor unit detects No ACK error/No response error, an object indoor unit is treated as a stop, and not assumed to be abnormal.
- Refer to the service manual of indoor unit or remote controller for the detail of error detected in indoor unit or remote controller.

### Self-diagnosis function

The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED1, LED2 (LED indication) found on the multi-controller of the outdoor unit.  
LED indication : Set all contacts of SW1 to OFF.


During normal operation

The LED indicates the drive state of the controller in the outdoor unit.

Bit	1	2	3	4	5	6	7	8
Indication	Compressor operated	52C	21S4	SV1	(SV2)	—	—	Always lit

### [Example]

When the compressor and SV1 are turned during cooling operation.



### 8-1-3. SELF-DIAGNOSIS ACTION BY FLOWCHART

Check code	
0403 (Ed)	Serial communication error

Abnormal points and detection methods	Causes and check points
Abnormal if serial communication between the outdoor multi controller circuit board and outdoor power circuit board is defective.	① Wire breakage or contact failure of connector CN2 or CN4 ② Malfunction of communication circuit to power circuit board on outdoor multi controller circuit board ③ Malfunction of communication circuit on outdoor power circuit board

●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check the connection of the communication line (CN2 and CN4) between the outdoor multi controller circuit board and power circuit board.</p> <pre> graph TD     A[Check the connection of the communication line (CN2 and CN4) between the outdoor multi controller circuit board and power circuit board.] --&gt; B{Are they connected normally?}     B -- No --&gt; C[Connect the CN2 and CN4 properly. Replace them in case of a breakage.]     B -- Yes --&gt; D[The communication circuit of either the outdoor multi controller circuit board or power circuit board is defective. If unable to identify the defective circuit; ①Replace the outdoor multi controller circuit board if it does not recover. ②Replace the outdoor power circuit board.]           </pre>	<p>Connect the CN2 and CN4 properly. Replace them in case of a breakage.</p> <p>The communication circuit of either the outdoor multi controller circuit board or power circuit board is defective. If unable to identify the defective circuit;            ①Replace the outdoor multi controller circuit board if it does not recover.            ②Replace the outdoor power circuit board.</p>


## Compressor temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
<p>(1) Abnormal if TH4 falls into following temperature conditions;</p> <ul style="list-style-type: none"> <li>●exceeds 230°F [110°C] continuously for 5 minutes</li> <li>●exceeds 257°F [125°C]</li> </ul> <p>(2) Abnormal if a pressure detected by the high-pressure sensor and converted to saturation temperature exceeds 104°F [40°C] during defrosting, and TH4 exceeds 230°F [110°C].</p> <p>TH4: Thermistor &lt;Compressor&gt; LEV: Electronic expansion valve</p>	<p>① Malfunction of stop valve</p> <p>② Over-heated compressor operation caused by shortage of refrigerant</p> <p>③ Defective thermistor</p> <p>④ Defective outdoor multi controller circuit board</p> <p>⑤ LEV performance failure</p> <p>⑥ Defective indoor controller board</p> <p>⑦ Clogged refrigerant system caused by foreign object</p> <p>⑧ Refrigerant shortage (Refrigerant liquid accumulation in compressor while indoor unit is OFF/thermo-OFF.)</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor temperature trouble

Chart 2 of 2

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## High pressure trouble

Chart 1 of 4

Abnormal points and detection methods	Causes and check points
<p>&lt;63H equipped model (63HS non-equipped)&gt;            (1) High pressure abnormality (63H operation)            Abnormal if 63H operates(*) during compressor operation. (* 602 PSIG)</p> <p>&lt;63HS equipped model (63H non-equipped)&gt;            (2) High pressure abnormality (63HS detected)            1. Abnormal if a pressure detected by 63HS is 625 PSIG or more during compressor operation.            2. Abnormal if a pressure detected by 63HS is 600 PSIG or more for 3 minutes during compressor operation.</p> <p>63H : High-pressure switch            63HS: High-pressure sensor            LEV : Electronic expansion valve            SV1 : Solenoid valve            TH7 : Thermistor &lt;Ambient&gt;</p>	<p>① Defective operation of stop valve (not fully open)            ② Clogged or broken pipe            ③ Malfunction or locked outdoor fan motor            ④ Short-cycle of outdoor unit            ⑤ Dirt of outdoor heat exchanger            ⑥ Remote controller transmitting error caused by noise interference            ⑦ Contact failure of the outdoor multi controller circuit board connector            ⑧ Defective outdoor multi controller circuit board            ⑨ Short-cycle of indoor unit            ⑩ Decreased airflow, clogged filter, or dirt on indoor unit.            ⑪ Malfunction or locked indoor fan motor            ⑫ Decreased airflow caused by defective inspection of outdoor temperature thermistor (It detects lower temperature than actual temperature.)            ⑬ Indoor LEV performance failure            ⑭ Malfunction of fan driving circuit            ⑮ SV1 performance failure            ⑯ Defective high-pressure sensor            ⑰ Defective high-pressure sensor input circuit on outdoor multi controller circuit board</p>

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<p>Is 5201 displayed when restarted?</p> <p>Yes (5201)</p> <p>No (1302)</p>	<p>Refer to the diagnosis of check code 5201.</p>
<p>Is the outdoor stop valve (liquid/gas) fully open?</p> <p>No</p> <p>Yes</p>	<p>Open the stop valve (liquid/gas) fully.</p>
<p>Does the outdoor fan rotate during the operation?</p> <p>No</p> <p>Yes</p>	<p>Check the outdoor fan motor. Refer to "How to check the parts" on the outdoor unit service manual.</p>
<p>Does the indoor fan rotate during the operation?</p> <p>No</p> <p>Yes</p>	<p>Check the indoor fan motor. Refer to "How to check the parts" on the indoor unit service manual.</p>
<p>Is the indoor unit short-cycled?</p> <p>Yes (short-cycled)</p> <p>No (no short-cycle)</p> <p>Continue to the next page</p>	<p>Solve the short-cycle.</p>

## High pressure trouble

Chart 2 of 4

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## High pressure trouble

Chart 3 of 4

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.






## High pressure trouble

Chart 4 of 4

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Superheat due to low discharge temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
<p>Abnormal if the discharge superheat is continuously detected <math>-27^{\circ}\text{F}</math> [<math>-15^{\circ}\text{C}</math>] or less (*) for 5 minutes even though the indoor LEV has minimum open pulse after the compressor starts operating for 10 minutes.</p> <p>LEV : Electronic expansion valve TH4 : Thermistor &lt;Compressor&gt; 63HS: High-pressure sensor</p> <p>*At this temperature, conditions for the abnormality detection will not be satisfied if no abnormality is detected on either TH4 or 63HS.</p>	<p>① Disconnection or loose connection of TH4 ② Defective holder of TH4 ③ Disconnection of LEV coil ④ Disconnection of LEV connector ⑤ LEV performance failure</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Superheat due to low discharge temperature trouble

Chart 2 of 2

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Refrigerant shortage trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
<p>(1) Abnormal when all of the following conditions are satisfied for 15 consecutive minutes:</p> <ol style="list-style-type: none"> <li>1.The compressor is operating in HEAT mode.</li> <li>2.Discharge super heat is 176°F [80°C] or more.</li> <li>3.Difference between TH7 and the TH3 applies to the formula of (TH7-TH3 &lt; 9°F [5°C])</li> <li>4.The saturation temperature converted from a high pressure sensor detects below 95°F [35°C].</li> </ol> <p>(2) Abnormal when all of the following conditions are satisfied:</p> <ol style="list-style-type: none"> <li>1.The compressor is in operation</li> <li>2.When cooling, discharge superheat is 176°F [80°C] or more, and the saturation temperature converted from a high pressure sensor is over -40°F [-40°C].</li> <li>When heating, discharge superheat is 194°F [90°C] or more.</li> </ol>	<ol style="list-style-type: none"> <li>① Defective operation of stop valve (not fully open)</li> <li>② Defective thermistor</li> <li>③ Defective outdoor multi controller circuit board</li> <li>④ Indoor LEV performance failure</li> <li>⑤ Gas leakage or shortage</li> <li>⑥ Defective 63HS</li> </ol> <p>TH3 : Thermistor &lt;Outdoor liquid pipe&gt;  TH7 : Thermistor &lt;Ambient&gt;  LEV : Electronic expansion valve  63HS : High-pressure sensor</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Refrigerant shortage trouble

Chart 2 of 2

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## Closed valve in cooling mode

Abnormal points and detection methods	Causes and check points
<p>Abnormal if stop valve is closed during cooling operation.</p> <p>Abnormal when both of the following temperature conditions are satisfied for 20 minutes or more during cooling operation.</p> <ol style="list-style-type: none"> <li>1. TH22j-TH21j <math>\geq -3.6^{\circ}\text{F}</math> [<math>-2^{\circ}\text{C}</math>]</li> <li>2. TH23j-TH21j <math>\geq -3.6^{\circ}\text{F}</math> [<math>-2^{\circ}\text{C}</math>]</li> </ol> <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<p>① Outdoor liquid/gas valve is closed. ② Malfunction of outdoor LEV (LEV1)(blockage)</p> <p>TH21: Indoor intake temperature thermistor TH22: Indoor liquid pipe temperature thermistor TH23: Indoor gas pipe temperature thermistor LEV: Electronic expansion valve</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<pre> graph TD     Q1{{Is the outdoor stop valve (liquid/gas) fully open?}}     Q1 -- No --&gt; R1[Open the outdoor stop valve (liquid/gas) fully.]     Q1 -- Yes --&gt; P1[Disconnect the outdoor LEV wiring to check the resistance.]     P1 --&gt; Q2{{Is there a resistance detected?}}     Q2 -- No --&gt; R2[Replace the outdoor LEV.]     Q2 -- Yes --&gt; R3[Replace the outdoor multi controller circuit board.]           </pre>	

## 4-way valve trouble in heating mode

Abnormal points and detection methods	Causes and check points
<p>Abnormal if 4-way valve does not operate during heating operation.</p> <p>Abnormal when any of the following temperature conditions is satisfied for 3 min. or more during heating operation</p> <ol style="list-style-type: none"> <li>1. <math>TH22j-TH21j \leq -18^{\circ}F [-10^{\circ}C]</math></li> <li>2. <math>TH23j-TH21j \leq -18^{\circ}F [-10^{\circ}C]</math></li> <li>3. <math>TH22j \leq 37.4^{\circ}F [3^{\circ}C]</math></li> <li>4. <math>TH23j \leq 37.4^{\circ}F [3^{\circ}C]</math></li> </ol> <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<ol style="list-style-type: none"> <li>① 4-way valve failure</li> <li>② Disconnection or failure of 4-way valve coil</li> <li>③ Clogged drain pipe</li> <li>④ Disconnection or loose connection of connectors</li> <li>⑤ Malfunction of input circuit on outdoor multi controller circuit board</li> <li>⑥ Defective outdoor power circuit board</li> </ol> <p>TH21: Indoor intake temperature thermistor TH22: Indoor liquid pipe temperature thermistor TH23: Indoor gas pipe temperature thermistor</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor current interruption (Locked compressor)

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
Abnormal if overcurrent of DC bus or compressor is detected within 30 seconds after the compressor starts operating.	① Closed stop valve ② Decrease of power supply voltage ③ Looseness, disconnection, or wrong phase of compressor wiring connection ④ Model selection error on indoor controller board or outdoor multi controller circuit board ⑤ Defective compressor ⑥ Defective outdoor power circuit board

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.






## Compressor current interruption (Locked compressor)

Chart 2 of 2

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor overcurrent interruption

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
Abnormal if overcurrent of DC bus or compressor is detected after 30 seconds since the compressor starts operating.	① Closed outdoor stop valve ② Decrease of power supply voltage ③ Looseness, disconnection, or wrong phase of compressor wiring connection ④ Model selection error on indoor controller board or outdoor multi controller circuit board ⑤ Defective compressor ⑥ Defective outdoor power circuit board ⑦ Defective outdoor multi controller circuit board ⑧ Malfunction of indoor/outdoor unit fan ⑨ Short-cycle of indoor/outdoor unit

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor overcurrent interruption

Chart 2 of 2

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



# Undervoltage/Overvoltage/PAM error/L1 open-phase/ Primary current sensor error/Power synchronization signal error


Chart 1 of 2

Abnormal points and detection methods	Causes and check points
<p>Abnormal if any of following symptoms are detected;</p> <ul style="list-style-type: none"> <li>● Decrease of DC bus voltage to 200 V</li> <li>● Increase of DC bus voltage to 400 V</li> <li>● DC bus voltage stays at 310 V or less for consecutive 30 seconds when the operational frequency is over 20 Hz.</li> <li>● When any of the following conditions are satisfied while the detection value of primary current is 0.1 A or less.</li> </ul> <p>1. The operational frequency is 40 Hz or more. 2. The compressor current is 6 A or more.</p>	<ul style="list-style-type: none"> <li>① Decrease/increase of power supply voltage,</li> <li>② Primary current sensor failure</li> <li>③ Disconnection of compressor wiring</li> <li>④ Malfunction of 52C</li> <li>⑤ Disconnection or contact failure of CN52C</li> <li>⑥ Defective outdoor power circuit board</li> <li>⑦ Malfunction of 52C driving circuit on outdoor multi controller circuit board</li> <li>⑧ Disconnection of CN5</li> <li>⑨ Disconnection of CN2</li> <li>⑩ Malfunction of primary current detecting circuit on outdoor power circuit board</li> </ul>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




Undervoltage/Overvoltage/PAM error/L1 open-phase/  
Primary current sensor error/Power synchronization signal error

Chart 2 of 2

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Heat sink temperature trouble

Abnormal points and detection methods	Causes and check points
<p>Abnormal if TH8 detects a temperature outside the specified range during compressor operation.</p> <p>TH8: Thermistor &lt;Heat sink&gt;</p>	<p>① Blocked outdoor fan</p> <p>② Malfunction of outdoor fan motor</p> <p>③ Blocked airflow path</p> <p>④ Rise of ambient temperature</p> <p>⑤ Characteristic defect of thermistor</p> <p>⑥ Malfunction of input circuit on outdoor power circuit board</p> <p>⑦ Malfunction of outdoor fan driving circuit</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Power module trouble or overcurrent trouble

Abnormal points and detection methods	Causes and check points
Abnormal if both of the following conditions are satisfied: 1. Overcurrent of DC bus or compressor is detected during compressor operation. 2. Inverter power module is determined to be defected.	① Short-circuit caused by looseness or disconnection of compressor wiring ② Defective compressor ③ Defective outdoor power circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Fan trouble (Outdoor unit)

Abnormal points and detection methods	Causes and check points
Abnormal if no rotational frequency is detected, or detected a value outside the specified range during fan motor operation.	① Malfunction of fan motor ② Disconnection of CNF connector ③ Defective outdoor multi controller circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.





## Check code

5101  
(U3)

## Compressor temperature thermistor (TH4) open/short


&lt;Detected in outdoor unit&gt;

Abnormal points and detection methods	Causes and check points
Abnormal if TH4 detects to be open/short. (The open/short detection is disabled for 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: 37.4°F [3°C] or less Short: 422.6°F [217°C] or more    TH4: Thermistor <Compressor>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor multi controller circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.



## Suction pipe temperature thermistor (TH6) open/short


&lt;Detected in outdoor unit&gt;

Abnormal points and detection methods	Causes and check points
<p>Abnormal if TH6 detects to be open/short.            (The open/short detection is disabled during 10 seconds to 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.)            Open: -40°F [-40°C] or less            Short: 194°F [90°C] or more TH6: Thermistor &lt;Suction pipe&gt;</p>	<p>① Disconnection or contact failure of connectors            ② Characteristic defect of thermistor            ③ Defective outdoor multi controller circuit board</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Outdoor liquid pipe temperature thermistor (TH3) open/short

Abnormal points and detection methods	Causes and check points
<p>Abnormal if TH3 detects to be open/short.            (The open/short detection is disabled during 10 seconds to 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.)            Open: -40°F [-40°C] or less            Short: 194°F [90°C] or more      TH3: Thermistor &lt;Outdoor liquid pipe&gt;</p>	<p>① Disconnection or contact failure of connectors            ② Characteristic defect of thermistor            ③ Defective outdoor multi controller circuit board</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Ambient thermistor (TH7) open/short

Abnormal points and detection methods	Causes and check points
Abnormal if TH7 detects to be open/short. Open: -40°F [-40°C] or less Short: 194°F [90°C] or more      TH7: Thermistor <Ambient>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor multi controller circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## HIC pipe temperature thermistor (TH2) open/short

Abnormal points and detection methods	Causes and check points
Abnormal if TH2 detects to be open/short. Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH2: Thermistor <HIC pipe>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor multi controller circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Heat sink temperature thermistor (TH8) open/short

Abnormal points and detection methods	Causes and check points
Abnormal if TH8 (Internal thermistor) detects to be open/short. Open: -31.2°F [-35.1°C] or more Short: 338.5°F [170.3°C] or less  TH8: Thermistor <Heat sink>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor multi controller circuit board

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## High pressure sensor (63HS) trouble

Abnormal points and detection methods	Causes and check points
<p>① When the detected pressure in the high pressure sensor is 14 PSIG or less during operation, the compressor stops operation and enters into an anti-restart mode for 3 minutes.</p> <p>② When the detected pressure is 14 PSIG or less immediately before restarting, the compressor falls into an abnormal stop with a check code &lt;5201&gt;.</p> <p>③ For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</p>	<p>① Defective high pressure sensor</p> <p>② Decrease of internal pressure caused by gas leakage</p> <p>③ Disconnection or contact failure of connector</p> <p>④ Malfunction of input circuit on outdoor multi controller circuit board</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Low pressure sensor (63LS) trouble

Abnormal points and detection methods	Causes and check points
<p>① When the detected pressure in the low pressure sensor is -33 PSIG or less, or 329 PSIG or more during operation, the compressor stops operation with a check code &lt;5202&gt;.</p> <p>② For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</p>	<p>① Defective low pressure sensor</p> <p>② Decrease of internal pressure caused by gas leakage</p> <p>③ Disconnection or contact failure of connector</p> <p>④ Malfunction of input circuit on outdoor multi controller circuit board</p>

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.






## Current sensor trouble/Primary current error

Abnormal points and detection methods	Causes and check points									
<p>Abnormal if any of the following conditions are detected:</p> <p>① Primary current sensor detects any of the following conditions (single phase unit only):</p> <table><tr><th>Ambient temperature</th><th>10 consecutive-second detection</th><th>One-time detection</th></tr><tr><td>TH7 &gt; 37.4°F [3°C]</td><td>37 A</td><td>40 A</td></tr><tr><td>TH7 ≤ 37.4°F [3°C]</td><td>40 A</td><td>43A</td></tr></table> <p>② Secondary current sensor detects 25 A or more.</p> <p>③ Secondary current sensor detects 1.0 A or less.</p>	Ambient temperature	10 consecutive-second detection	One-time detection	TH7 > 37.4°F [3°C]	37 A	40 A	TH7 ≤ 37.4°F [3°C]	40 A	43A	<p>① Decrease/trouble of power supply voltage</p> <p>② Disconnection of compressor wiring</p> <p>③ Current sensor trouble on outdoor power circuit board</p> <p>④ Wiring through current sensor (penetration type) is not done.</p>
Ambient temperature	10 consecutive-second detection	One-time detection								
TH7 > 37.4°F [3°C]	37 A	40 A								
TH7 ≤ 37.4°F [3°C]	40 A	43A								

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.



## Duplex address error

Abnormal points and detection methods	Causes and check points
Abnormal if 2 or more units with the same address are existing.	① There are 2 units or more with the same address in their controller among outdoor unit, indoor unit, Fresh Master, Lossnay or remote controller ② Noise interference on indoor/outdoor connectors

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Search for a unit with the same address as the source of abnormality.</p> <pre> graph TD     A[Search for a unit with the same address as the source of abnormality.] --&gt; B{Is there any unit with the same address?}     B -- Yes --&gt; C[Correct the address, and turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.]     B -- No --&gt; D[Turn the power back ON.]     D --&gt; E{Does it operate normally?}     E -- No --&gt; F[Malfunction of sending/receiving circuit on indoor/outdoor unit is suspected.]     E -- Yes --&gt; G[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	
	<p>Correct the address, and turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.</p>
	<p>Malfunction of sending/receiving circuit on indoor/outdoor unit is suspected.</p>
	<p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## Transmission processor hardware error

Abnormal points and detection methods	Causes and check points
Abnormal if the transmission line shows "1" although the transmission processor transmitted "0".	① A transmitting data collision occurred because of a wiring work or polarity change has performed while the power is ON on either of the indoor/outdoor unit, Fresh Master or Lossnay ② Malfunction of transmitting circuit on transmission processor ③ Noise interference on indoor/outdoor connectors

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<pre> graph TD     Q1{{A wiring work was performed while the power OFF.}}     Q1 -- No --&gt; R1[If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.]     Q1 -- Yes --&gt; P1[Turn the power back ON.]     P1 --&gt; Q2{{Does it operate normally?}}     Q2 -- No --&gt; R2[Replace the indoor/outdoor controller board.]     Q2 -- Yes --&gt; R3[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<div> <p>If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.</p> </div> <div> <p>Replace the indoor/outdoor controller board.</p> </div> <div> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p> </div>

## Transmission bus BUSY error

Abnormal points and detection methods	Causes and check points
<p>① Over error by collision Abnormal if no-transmission status caused by a transmitting data collision is consecutive for 8 to 10 minutes.</p> <p>② Abnormal if a status, that data is not allowed on the transmission line because of noise and such, is consecutive for 8 to 10 minutes.</p>	<p>① The transmission processor is unable to transmit due to a short-cycle voltage such as noise is mixed on the transmission line.</p> <p>② The transmission processor is unable to transmit due to an increase of transmission data amount caused by a miswiring of the terminal block (transmission line) (TB3) and the terminal block (centralized control line) (TB7) on the outdoor unit.</p> <p>③ The share on transmission line becomes high due to a mixed transmission caused by a malfunction of repeater on the outdoor unit, which is a function to connect/disconnect transmission from/to control system and centralized control system.</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## Signal communication error with transmission processor

Abnormal points and detection methods	Causes and check points
① Abnormal if the data of unit/transmission processor were not normally transmitted. ② Abnormal if the address transmission from the unit processor was not normally transmitted.	① Accidental disturbance such as noise or lightning surge ② Hardware malfunction of transmission processor

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.</p> <pre> graph TD     A[Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.] --&gt; B{Does it operate normally?}     B -- No --&gt; C[Replace the controller. (Defect of error source controller).]     B -- Yes --&gt; D[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<p>Replace the controller. (Defect of error source controller).</p> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## No ACK error

Chart 1 of 4

Abnormal points and detection methods	Causes and check points
<p>① Represents a common error detection An abnormality detected by the sending side controller when receiving no ACK from the receiving side, though signal was once sent. The sending side searches the error in 30 seconds interval for 6 times continuously.</p>	<p>① The previous address unit does not exist since the address switch was changed while in electric continuity status.</p> <p>② Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 656 ft [200 m] ·On remote controller line: 39 ft [12 m]</p> <p>③ Decline of transmission voltage/signal due to unmatched transmission line types ·Types for shield line: CVVS, CPEVS or MVVS ·Line diameter: AWG 16 [1.25 mm<sup>2</sup>] or more</p> <p>④ Decline of transmission voltage/signal due to excessive number of connected units</p> <p>⑤ Malfunction due to accidental disturbance such as noise or lightning surge</p> <p>⑥ Defect of error source controller</p>
<p>② The cause of displayed address and attribute is on the outdoor unit side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the outdoor unit.</p>	<p>① Contact failure of indoor/outdoor unit transmission line.</p> <p>② Disconnection of transmission connector (CN2M) on indoor unit.</p> <p>③ Malfunction of sending/receiving circuit on indoor/outdoor unit.</p>
<p>③ The cause of displayed address and attribute is on the indoor unit side. An abnormality detected by the remote controller if receiving no ACK when sending data from the remote controller to the indoor unit.</p>	<p>① While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON.</p> <p>② Contact failure of indoor unit or remote controller transmission line</p> <p>③ Disconnection of transmission connector (CN2M) on indoor unit</p> <p>④ Malfunction of sending/receiving circuit on indoor unit or remote controller</p>
<p>④ The cause of the displayed address and attribute is on the remote controller side An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the remote controller.</p>	<p>① While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON.</p> <p>② Contact failure of indoor unit or remote controller transmission line</p> <p>③ Disconnection of transmission connector (CN2M) on indoor unit</p> <p>④ Malfunction of sending/receiving circuit on indoor unit or remote controller</p>


## No ACK error

Chart 2 of 4

Abnormal points and detection methods	Causes and check points
<p>⑤ The cause of displayed address and attribute is on the Fresh Master side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the Fresh Master.</p>	<p>① While the indoor unit is operating with multi refrigerant system Fresh Master, an abnormality is detected when the indoor unit transmits signal to the remote controller while the outdoor unit with the same refrigerant system as the Fresh Master is turned OFF, or within 2 minutes after it turned back ON.</p> <p>② Contact failure of indoor unit or Fresh Master transmission line</p> <p>③ Disconnection of transmission connector (CN2M) on indoor unit or Fresh Master</p> <p>④ Malfunction of sending/receiving circuit on indoor unit or Fresh Master</p>
<p>⑥ The cause of displayed address and attribute is on Lossnay side. An abnormality detected by the indoor unit if receiving no ACK when the indoor unit transmit signal to the Lossnay.</p>	<p>① An abnormality is detected when the indoor unit transmits signal to Lossnay while the Lossnay is turned OFF.</p> <p>② While the indoor unit is operating with the other refrigerant Lossnay, an abnormality is detected when the indoor unit transmits signal to the Lossnay while the outdoor unit with the same refrigerant system as the Lossnay is turned OFF, or within 2 minutes after it turned back ON.</p> <p>③ Contact failure of indoor unit or Lossnay transmission line</p> <p>④ Disconnection of transmission connector (CN2M) on indoor unit</p> <p>⑤ Malfunction of sending/receiving circuit on indoor unit or Lossnay</p>
<p>⑦ The controller of displayed address and attribute is not recognized</p>	<p>① The previous address unit does not exist since the address switch was changed while in electric continuity status.</p> <p>② An abnormality detected at transmitting from the indoor unit since the Fresh Master/Lossnay address are changed after synchronized setting of Fresh Master/Lossnay by the remote controller.</p>

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.






## No ACK error

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## No response frame error

Abnormal points and detection methods	Causes and check points
Abnormal if receiving no response command while already received ACK. The sending side searches the error in 30 seconds interval for 6 times continuously.	① Continuous failure of transmission due to noise, etc ② Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 656 ft [200 m] ·On remote controller line: 39 ft [12 m] ③ Decline of transmission voltage/signal due to unmatched transmission line types ·Types for shield line: CVVS, CPEVS or MVVS ·Line diameter: AWG 16 [1.25 mm <sup>2</sup> ] or more ④ Accidental malfunction of error source controller

## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## MA communication receive error

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
<p>Detected in remote controller or indoor unit:</p> <p>① When the main or sub remote controller cannot receive signal from indoor unit which has the "0" address.</p> <p>② When the sub remote controller cannot receive signal.</p> <p>③ When the indoor controller board cannot receive signal from remote controller or another indoor unit.</p> <p>④ When the indoor controller board cannot receive signal.</p>	<p>① Contact failure of remote controller wirings</p> <p>② Irregular Wiring (A wiring length, number of connecting remote controllers or indoor units, or a wiring thickness does not meet the conditions specified in the chapter "Electrical Work" in the indoor unit Installation Manual.)</p> <p>③ Malfunction of the remote controller sending/receiving circuit on indoor unit with the LED2 is blinking.</p> <p>④ Malfunction of the remote controller sending/receiving circuit</p> <p>⑤ Remote controller transmitting error caused by noise interference</p>

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards



## MA communication receive error

Chart 2 of 2

## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards

Diagnosis	Remedy
<p>Continued from the previous page</p> <pre> graph TD     Start[Continued from the previous page] --&gt; Refer[Refer to the chapter "Electrical Work".]     Refer --&gt; Decision{Is the wiring connected properly, meeting the condition?}     Decision -- No --&gt; Remedy1[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.]     Decision -- Yes --&gt; Remedy2[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<p>Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.</p> <p>No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>


## MA communication send error

Chart 1 of 2

Abnormal points and detection methods	Causes and check points
Detected in remote controller or indoor unit.	① There are 2 remote controllers set as main. ② Malfunction of remote controller sending/receiving circuit ③ Malfunction of sending/receiving circuit on indoor controller board ④ Remote controller transmitting error caused by noise interference


## ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards



## •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards

Diagnosis	Remedy
Continued from the previous page	
 <pre>graph TD; A[Refer to the chapter "Electrical Work".] --&gt; B{Is the wiring connected properly, meeting the condition?}; B -- No --&gt; C[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.]; B -- Yes --&gt; D[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).];</pre>	

**Check code**
**7100**  
(EF)

# Total capacity error

Abnormal points and detection methods	Causes and check points
When the total capacity of connected indoor units exceeds the specified capacity (130% of the outdoor unit capacity), a check code <7100> is displayed.	① The total capacity of connected indoor units exceeds the specified capacity. · P60 model: up to code 56  ② The model name code of the outdoor unit is registered wrongly.

**●Diagnosis of defectives**

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check the total capacity of connected indoor units.</p> <p>Is the total under 130% of outdoor unit capacity?</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>Check the capacity code switch (SW2 on the indoor controller board) on the connected indoor unit.</p> <p>Is it set properly?</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>Check the model selection switch (SW4 on the outdoor multi controller circuit board) of the outdoor unit.</p> <p>Is it set properly?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Correct it so that the total capacity of connected indoor units is under 130% of the outdoor unit capacity.</p> <p>Set the switch properly.</p> <p>Set the switch properly.</p> <p>Complete</p>

# Check code

7101  
(EF)

## Capacity code error

Abnormal points and detection methods	Causes and check points
When a connected indoor unit is incompatible, a check code <7101> is displayed.	<p>The model name of connected indoor unit (model code) is read as incompatible.</p> <p>The connectable indoor units are:</p> <ul style="list-style-type: none"> <li>· P60 model: P06 to P72 model (code 4 to 40)</li> </ul>

### •Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check the model selection switch (refer to indoor unit service manual) of the connected indoor unit.</p> <p>Is it set properly?</p> <p>No</p> <p>Yes</p>	<p>Set the switch properly.</p> <p>The model code of the connected indoor unit can be displayed by an operation of SW1 on the outdoor unit.</p>



# Check code

7102  
(EF)

## Connecting unit number error

Abnormal points and detection methods	Causes and check points
When the connected indoor unit exceeds the limit, a check code <7102> is displayed.	<p>Connecting more indoor units and branch boxes than the limit.</p> <p>Abnormal if connecting status does not comply with the following limit;</p> <p>① Connectable up to 12 indoor units</p> <p>② Connect at least 1 indoor unit (Abnormal if connected none).</p> <p>③ Connectable only 1 ventilation unit</p>

### ●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check whether the connecting unit exceeds the limit or not.</p> <p>Does it exceed the limit?</p> <p>Yes</p> <p>No</p> <p>Check if at least 1 indoor unit is connected.</p> <p>Is an indoor unit connected?</p> <p>No</p> <p>Yes</p>	<p>Connect less number of units than the limit.</p> <p>The model code of the connected indoor unit can be displayed by an operation of SW1 on the outdoor unit.</p> <p>Connect indoor unit.</p> <p>Check whether the M-NET line to the indoor unit is connected or not.</p>

Check code

7105  
(EF)

## Address setting error

Abnormal points and detection methods	Causes and check points
The address setting of connected unit is wrong.	There is a unit without correct address setting in the range specified in "7-4. SYSTEM CONTROL".

•Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p><b>&lt;Outdoor unit&gt;</b></p> <pre> graph TD     A[Check whether the outdoor unit address is set in 000, or in the range of 51 to 100.] --&gt; B{Is the address setting correct?}     B -- No --&gt; C[Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.]     B -- Yes --&gt; D[Replace the outdoor multi controller circuit board.]                     </pre>	

Check code

7130  
(EF)

## Incompatible unit combination error

Abnormal points and detection methods	Causes and check points
When the connected indoor unit is not connectable with the outdoor unit, the outdoor unit detects the error at start-up.	Connecting indoor unit (s) which is not authorized to connect to the outdoor unit.

●Diagnosis of defectives

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Refer to the service manual of the outdoor unit or the connected indoor unit for the authorized combination.</p> <pre> graph TD     A[Refer to the service manual of the outdoor unit or the connected indoor unit for the authorized combination.] --&gt; B{Is the indoor unit authorized to connect with the outdoor unit?}     B -- No --&gt; C[Replace the indoor unit (s) to the connectable one.]     B -- Yes --&gt; D{Check whether the model selection switch is set correctly. Are they correct?}     D -- No --&gt; E[Set the model selection switch correctly, then restart.]     D -- Yes --&gt; F[Replace the outdoor controller board.]                     </pre>	

## 8-2. REMOTE CONTROLLER DIAGNOSIS

For the detailed procedure, refer to the remote controller's manuals.

## 8-3. REMOTE CONTROLLER TROUBLE




For the troubleshooting, refer to the remote controller's manuals.

## 8-4. THE FOLLOWING SYMPTOM DO NOT REPRESENT TROUBLE (EMERGENCY)

Symptom	Display of remote controller	CAUSE
Even the cooling (heating) operation selection button is pressed, the indoor unit cannot be operated.	"Cooling (Heating)" blinks	The indoor unit can not cool (Heat) if other indoor units are heating (Cooling).
The auto vane runs freely.	Normal display	Because of the control operation of auto vane, it may change over to horizontal blow automatically from the downward blow in cooling in cause the downward blow operation has been continued for 1 hour. At defrosting in heating, hot adjusting and thermostat OFF, it automatically changes over to horizontal blow.
Fan setting changes during heating.	Normal display	Ultra-low speed operation is commenced at thermostat OFF. Light air automatically change over to set value by time or piping temperature at thermostat ON.
Fan stops during heating operation.	"Defrost ☆"	The fan is to stop during defrosting.
Fan does not stop while operation has been stopped.	Light out	Fan is to run for 1 minute after stopping to exhaust residual heat (only in heating).
No setting of fan while start SW has been turned on.	STAND BY ☆	Ultra-low speed operation for 5 minutes after SW ON or until piping temperature becomes 35°C. There low speed operate for 2 minutes, and then set notch is commenced. (Hot adjust control)
Indoor unit remote controller shows "HO" or "PLEASE WAIT" indicator for about 2 minutes when turning ON power supply.	"HO" blinks "PLEASE WAIT" blinks	System is being driven. Operate remote controller again after "HO" or "PLEASE WAIT" disappears.
Drain pump does not stop while unit has been stopped.	Light out	After a stop of cooling operation, unit continues to operate drain pump for 3 minutes and then stops it.
Drain pump continues to operate while unit has been stopped.	—	Unit continues to operate drain pump if drainage is generated, even during a stop.

## 8-5. INTERNAL SWITCH FUNCTION TABLE PUMY-P60NKMU1(-BS)

The black square (■) indicates a switch position.

Switch	Step	Function	Operation in Each Switch Setting		Remarks	Purpose	Additional Information						
			ON	OFF									
SWU1 ones digit SWU2 tens digit	Rotary switch	 (tens digit) (ones digit)		Before turning the power ON	<Initial settings>  (tens digit) (ones digit)								
	1-8	 ON OFF 1 2 3 4 5 6 7 8		Can be set either during operation or not.	<Initial settings> ON OFF 1 2 3 4 5 6								
	1	Selects operating system startup	With centralized controller	Without centralized controller	Before turning the power ON	<Initial settings> ON OFF 1 2 3 4	Turn ON when the centralized controller is connected to the outdoor unit.	SW2-1 must be turned ON if a central controller is connected to the system. An example of this would be a TC-24, EW-50A, AG150, AE50 or AE200. If SW2-1 is not turned on, while using a central controller, in rare circumstances problems may be encountered such as indoor units not responding to group commands. Therefore, turning SW2-1 ON is recommended if a central controller is used.					
SW2 Function Switch	2	Connection Information Clear Switch	Clear	Do not clear		When relocating units or connecting additional units.	—						
	3	Abnormal data clear switch input	Clear abnormal data	Normal	OFF to ON any time after the power is turned on.	To delete an error history.							
	4	Pump down	Run adjustment mode	Normal	During compressor running	To facilitate outdoor unit the pumping down operation. Frequency = Fixed to 65 Hz Indoor-electronic expansion valve = Fully open Outdoor fan step = Fixed to 10	Please refer to a section referring to the pumping down on outdoor units Installation Manuals. It might not be possible to collect all the refrigerant if the amount is excessive.						
SW2-5, 6/ SW4/ SW8 Model Switch	1-6	MODEL SELECTION 1:ON 0:OFF <table border="1"><tr><td>MODEL</td><td>SW4</td><td>SW8</td></tr><tr><td>PUMY-P60NKMU1</td><td>ON OFF 1 2 3 4 5 6</td><td>ON OFF 1 2</td></tr></table>	MODEL	SW4	SW8	PUMY-P60NKMU1	ON OFF 1 2 3 4 5 6	ON OFF 1 2		Before the power is turned ON.	<Initial settings> Set for each capacity.		—
MODEL	SW4	SW8											
PUMY-P60NKMU1	ON OFF 1 2 3 4 5 6	ON OFF 1 2											
SW3 Trial operation	1	ON/OFF from outdoor unit	ON	OFF	<Initial settings> ON OFF 1 2		—						
	2	Mode setting	Heating	Cooling			—						
SW5 Function switch	1	—	—	—		To set the LEV opening at start-up higher than usual. (+150 pulses) To improve the operation with the LEV almost clogged.	The refrigerant flow noise at start-up become louder.						
	2	Change the indoor unit's LEV opening at start-up	Enable	Normal	Can be set when off or during operation								
	3	—	—	—		<Initial settings> ON OFF 1 2 3 4 5 6 7 8	Turn ON when an auxiliary heater is connected. (It transmits a connection permission signal of the auxiliary heater to the connected CITY MULTI indoor unit.)						
	4	Auxiliary heater	Enable	Disable	Before the power is turned ON.		Turn ON only when the auxiliary heater is connected and operated.						
	5	Change the indoor unit's LEV opening at defrost	Enable	Normal	Can be set when OFF or during operation	To set the LEV opening higher than usual during defrosting operation. (Only Oj ≤ 10 is valid. + 300 pulses) To avoid the discharge temperature increase and provide efficient defrosting operation.	The refrigerant flow noise during the defrosting operation becomes louder.						
	6	Switching the target sub cool (Heating mode)	Enable	Normal		To decrease the target sub cool value. To reduce the discharge temperature decrease due to refrigerant liquid accumulation in the units.	A refrigerant flow noise might be generated if the sub cool value is too small.						

Continue to the next page

Switch	Step	Function	Operation in Each Switch Setting		Remarks	Purpose	Additional Information
			ON	OFF			
SW5 Function switch	7	During the outdoor unit is in HEAT operation, additionally increase about 50 to 70 pulses of the LEV opening on the indoor unit which is in FAN, STOP, COOL or thermo-OFF.*1	Active	Inactive	Can be set when OFF or during operation	To additionally increase about 50 to 70 pulses of the LEV opening for units other than in HEAT operation. To avoid a refrigerant shortage (less capacity) due to refrigerant liquid accumulation in the units which is not in operation.	A refrigerant flow noise might be generated in units other than the one in operation.
	8	During the outdoor unit is in operation, fully closes the electronic expansion valve on the indoor unit which is in FAN, COOL, STOP, or thermo-OFF.*2	Enable	Normal	Before turning the power ON.	To reduce the room temperature increase by setting the LEV opening lower for the units in thermo-OFF operation.	The refrigerant is more likely to collect in the units with thermo-OFF operation, and causing the units refrigerant shortage. (Results in less capacity and increase of discharge temperature.)
	1	—	—	—	—	—	—
SW6 Function switch	2	—	—	—	—	—	—
	3	—	—	—	—	—	—
	4	Change of defrosting control	Enable (For high humidity)	Normal	Can be set when OFF or during operation	To shorten the defrosting prohibition time in high humidity (or heavy snow) region, in order to reduce malfunctions caused by frost.	The performance of the HEAT operation is somewhat reduced since the defrosting operation is frequently performed.
	5	Ignore refrigerant filling abnormality	Enable	Normal	Can be set when OFF or during operation	To ignore the error detection of excessive charge of refrigerant. The unit can be excessively charged with refrigerant depending on the operating condition.	Make sure that the unit is not excessively charged with refrigerant before starting operation when servicing or installing the units.
	6	Switching the target discharge pressure (Pdm)	Enable	Normal	Can be set when OFF or during operation	To raise the performance by setting the Pdm higher during HEAT operation.	Power consumption is raised due to a higher frequency. (The performance would not be raised at the maximum operating frequency.)
	7	Switching (1) the target evaporation temperature (ETm)	Enable	Normal	SW6-7 SW6-8 Target ETm (°C)	To raise/reduce the performance by changing the target ETm during COOL operation.	Switching it to raise the performance. It raises the power consumption, and produces more dew condensation.
	8	Switching (2) the target evaporation temperature (ETm)	Enable	Normal	SW6-8 Target Pdm (kg/cm <sup>2</sup> )	Switch to raise the performance: raises the performance Switch to reduce the performance: prevents dew condensation	Switching it to reduce the performance, it makes the performance insufficient.
	1	Ignore current sensor abnormality	Enable	Normal	After turning the power ON.	To perform a test run for electrical parts alone without running the compressor.	Make sure to connect the connectors to the compressor after checking the electrical parts. Be careful not to get electrical shock while working on electrical parts.
SW7 Function switch	2	Setting to energize the freeze stat heater (optional part)	During heating operation only*3	Include when the heating operation is OFF.*4	Can be set when OFF or during operation	It reduces snow on the base, even it blows inside the unit, by setting the base heater ON while the HEAT operation is stopped.	Power consumption raises while the operation is stopped.
	3	High heating performance mode	Enable	Normal	Anytime	To raise the performance of HEAT operation if it is insufficient.	The performance may not be raised depending on the capacity of indoor units in operation, or outside air temperature.
	4	—	—	—	—	—	—
	5	Simultaneous cooling and heating with external heater	Enable	Disable	Anytime	The simultaneous operation of cooling and heating will be possible by installing an external heater to the CITY MULTI indoor unit.	For the installation of external heater and the indoor unit setting, refer to the indoor unit service manual.
	6	Manual defrost	Manual defrost	Normal	During compressor running in HEAT mode.	Turn ON when it is necessary to perform the defrosting operation forcibly. (Effective only at start-up, or 10 minutes after the last defrosting operation)	It performs the defrosting operation forcibly. (HEAT operation is stopped temporarily.)
SW9 Function Switch	1	Auto change over from remote controller (IC with the minimum address)	Enable	Disable	Before turning the power ON	Enables the indoor unit with the minimum address to select AUTO mode, and switches the operation mode of the other indoor units to the same mode.	Cannot be set when the centralized control is ON.
	2	Switching the Silent/ Demand mode	Demand control	Silent mode	Can be set when OFF or during operation	—	About the Silent mode/Demand control setting, refer to "8.8. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR".
	3	—	—	—	—	—	—
	4	—	—	—	—	—	—

\*1 SW5-7 Opens the indoor-electronic expansion valve as a countermeasure against the indoor unit in FAN, COOL, STOP, or thermo-OFF operation with refrigerant-shortage status due to an accumulation of liquid refrigerant in the indoor unit.


\*2 SW5-8 Countermeasure against room temperature rise for indoor unit in FAN, COOL, and thermo-OFF (heating) mode.

\*3 During heating operation and the ambient temperature is 4°C or below, the freeze prevention heater is energized.

\*4 During heating mode is OFF (include thermo-OFF in cooling mode), and the ambient temperature is 4°C or below, the freeze prevention heater is energized.

## 8-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR


### • State (CN51)



- Ⓐ Distant control board
- Ⓑ Relay circuit
- Ⓒ External output adapter (PAC-SA88HA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Lamp power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

L1: Error display lamp  
 L2: Compressor operation lamp  
 X, Y: Relay (Coil standard of 0.9W or less for 12 V DC)  
 X, Y: Relay (1 mA DC)


### • Auto change over (CN3N)



- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

	ON	OFF
SW1	Heating	Cooling
SW2	Validity of SW1	Invalidity of SW1

### • Silent Mode/Demand Control (CN3D)







- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

The silent mode and the demand control are selected by switching the DIP switch 9-2 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1, 2.

	Outdoor controller board DIP SW9-2	SW1	SW2	Function
Silent mode	OFF	ON	—	Silent mode operation
Demand control	ON	OFF	OFF	100% (Normal)
		ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)

## 8-7. HOW TO CHECK THE PARTS

### PUMY-P60NKMU1(-BS)

Parts name	Check points				
Thermistor (TH2) <Hic pipe> Thermistor (TH3) <Outdoor liquid pipe> Thermistor (TH4) <Compressor> Thermistor (TH6) <Suction pipe> Thermistor (TH7) <Ambient>	Disconnect the connector then measure the resistance with a tester. (At the ambient temperature 10 to 30℃)				
		Normal	Abnormal		
	TH4	160 to 410 kΩ	Open or short		
	TH2	4.3 to 9.6 kΩ			
	TH3				
	TH6 TH7				
Fan motor (MF1, MF2)	Measure the resistance between the conector pins with a tester. (At the ambient temperature 20℃)				
	Normal				Abnormal
	Red - Blue	Brown - Blue	Orange - Blue	White - Blue	Open or short (Short, for White - Blue)
	1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22 kΩ	Open	
Solenoid valve coil <4-way valve> (21S4)	Measure the resistance between the terminals with a tester. (At the ambient temperature 20℃)				
	Normal		Abnormal		
	1580 ± 110 Ω		Open or short		
Motor for compressor (MC)	Measure the resistance between the terminals with a tester. (Winding temperature 20℃)				
	Normal		Abnormal		
	0.370 ± 0.019 Ω		Open or short		
Solenoid valve coil <Bypass valve> (SV1)	Measure the resistance between the terminals with a tester. (At the ambient temperature 20℃)				
	Normal		Abnormal		
	1197 ± 10 Ω		Open or short		
Linear expansion Valve (LEV A)					
	Normal				Abnormal
	Gray - Black	Gray - Red	Gray - Yellow	Gray - Orange	Open or short
	46 ± 3 Ω				
Linear expansion Valve (LEV B)					
	Normal				Abnormal
	Red - White	Red - Orange	Red - Yellow	Red - Blue	Open or short
	46 ± 4 Ω				



## Check method of DC fan motor (fan motor / outdoor multi controller circuit board)

### ① Notes


1. High voltage is applied to the connector (CNF1, 2) for the fan motor. Pay attention to the service.
2. Do not pull out the connector (CNF1, 2) for the motor with the power supply on.  
(It causes trouble of the outdoor multi controller circuit board and fan motor.)

### ② Self check

Symptom : The outdoor fan can not turn around.


#### Fuse check

Check the fuse (F500) on outdoor controller board.



#### Wiring contact check

Contact of fan motor connector (CNF1, 2)





#### Power supply check(Remove the connector (CNF1, 2))

Measure the voltage in the outdoor multi controller circuit board.



TEST POINT ① :  $V_{DC}$  (between 1 (+) and 4 (-) of the fan connector):  $V_{DC}$  290~330 V DC(When PAM stops), 350 V DC (When PAM is operating)

TEST POINT ② :  $V_{CC}$  (between 5 (+) and 4 (-) of the fan connector):  $V_{CC}$  15 V DC






- The inverter control P.C. board is built in the fan motor of this outdoor unit.
- When F500 that is on multi controller board is blown, change the fan motor and multi controller board at the same time (F500 is impossible to change).
- For outdoor unit, there are 2 fan motors (up and down; MF1/MF2), it is possible to connect to either CNF1 or CNF2 on the board.
- It is abnormal when the abnormality is detected from either both fan motors or only one side.



## Check method of multi controller circuit board



## Check method of power circuit board



## Check method of M-NET power circuit board



## 8-8. HOW TO CHECK THE COMPONENTS

### <Thermistor feature chart>

#### Low temperature thermistors


- Thermistor <Hic pipe> (TH2)
- Thermistor <Outdoor liquid pipe> (TH3)
- Thermistor <Suction pipe> (TH6)
- Thermistor <Ambient> (TH7)

Thermistor R0 = 15 kΩ ± 3 %

B constant = 3480 ± 2 %

$$R_t = 15 \exp\left\{3480 \left( \frac{1}{273+t} - \frac{1}{273} \right)\right\}$$

32°F [0°C]	15 kΩ	86°F [30°C]	4.3 kΩ
50°F [10°C]	9.6 kΩ	104°F [40°C]	3.0 kΩ
68°F [20°C]	6.3 kΩ		
77°F [25°C]	5.2 kΩ		



#### High temperature thermistor


- Thermistor <Compressor> (TH4)

Thermistor R120 = 7.465 kΩ ± 2 %

B constant = 4057 ± 2 %

$$R_t = 7.465 \exp\left\{4057 \left( \frac{1}{273+t} - \frac{1}{393} \right)\right\}$$

68°F [20°C]	250 kΩ	158°F [70°C]	34 kΩ
86°F [30°C]	160 kΩ	176°F [80°C]	24 kΩ
104°F [40°C]	104 kΩ	194°F [90°C]	17.5 kΩ
122°F [50°C]	70 kΩ	212°F [100°C]	13.0 kΩ
140°F [60°C]	48 kΩ	230°F [110°C]	9.8 kΩ



## <HIGH PRESSURE SENSOR>

### • Comparing the High Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the high pressure sensor appears on the LED1 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

#### (1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

#### (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1,2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)

- 1) When the difference between both pressures is within 36 PSIG [0.25 MPaG], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 36 PSIG [0.25 MPaG], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1, 2 does not change, the high pressure sensor has a problem.

#### (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1, 2.

- 1) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 725 PSIG [5.0 MPaG], the control board has a problem.

#### (4) Remove the high pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63HS) to check the pressure with self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.



### • High Pressure Sensor Configuration (63HS)

The high pressure sensor consists of the circuit shown in the figure below. If 5 V DC is applied between the white and the black wires, voltage corresponding to the pressure between the blue and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.078 V per 14 PSIG [0.098 MPaG].

Note:

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.



	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



## <LOW PRESSURE SENSOR>

### • Comparing the Low Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the low pressure sensor appears on the LED1 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

#### (1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- When the outdoor temperature is 86°F [30°C] or less, and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (3).  
When the outdoor temperature exceeds 86°F [30°C], and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (5).

- If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

#### (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)

- When the difference between both pressures is within 29 PSIG [0.2MPaG], both the low pressure sensor and the control board are normal.
- When the difference between both pressures exceeds 29 PSIG [0.2MPaG], the low pressure sensor has a problem. (performance deterioration)
- When the pressure displayed on the self-diagnosis LED1, 2 does not change, the low pressure sensor has a problem.

#### (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1, 2 display.

- When the pressure displayed on the self-diagnosis LED1,2 is between 0 and 14 PSIG [0.098 MPaG], the low pressure sensor has a problem.
- When the pressure displayed on self-diagnosis LED1, 2 is approximately 247 PSIG [1.7 MPaG], the control board has a problem.

#### (4) Remove the low pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63LS) to check the pressure with the self-diagnosis LED1, 2.

- When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the low pressure sensor has a problem.
- If other than 1), the control board has a problem.

#### (5) Remove the high pressure sensor (63HS) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1, 2.

- When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the control board has a problem.
- If other than 1), go to (2).


### • Low Pressure Sensor Configuration (63LS)

The low pressure sensor consists of the circuit shown in the figure below. If 5 V DC is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173 V per 14 PSIG [0.098 MPaG].

Note:


The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



- ③—① : 5 V (DC)  
②—① : Output Vout (DC)

Pressure: 0–247 PSIG [1.7 MPaG]  
Vout: 0.5–3.5 V  
0.173 V/14 PSIG [0.098 MPaG]






## 8-9. TEST POINT DIAGRAM

### Outdoor multi controller circuit board PUMY-P60NKMU1(-BS)

<CAUTION> TEST POINT ① is high voltage.





## Outdoor power circuit board PUMY-P60NKMU1(-BS)

### Brief Check of POWER MODULE

Usually, they are in a state of being short-circuited if they are broken. Measure the resistance in the following points (connectors, etc.). If they are short-circuited, it means that they are broken.

#### 1. Check of POWER MODULE

##### ① Check of DIODE circuit

**[R]-L1, [S]-L1, [R]-N1, [S]-N1**


##### ② Check of IGBT circuit

**[L2]-N1**

##### ③ Check of INVERTER circuit

**[P]-U, [P]-V, [P]-W, [N1]-U, [N1]-V, [N1]-W**

Note: The marks **[R]**, **[S]**, **[L1]**, **[L2]**, **[P]**, **[N1]**, **[U]**, **[V]** and **[W]** shown in the diagram are not actually printed on the board.




# M-NET power circuit board PUMY-P60NKMU1(-BS)

**TB1**  
Connect to  
the electrical  
parts box

**CN2**  
Connect to the outdoor multi  
controller circuit board (CN102)  
①—②: 24–30 V DC  
③—④: 24–30 V DC

**CN1**  
• Connect to the outdoor  
noise filter circuit board  
(CNAC1) (Y)  
• Connect to the outdoor  
power circuit board (CNAC1) (V)  
①—③ : 208/230 V AC



## 8-10. OUTDOOR UNIT FUNCTIONS

SW:setting  
0...OFF  
1...ON

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
0	00000000	Relay output display Check display	Compressor operation 0000-9999 (Alternating display of addresses and check code)	52C	21S4	SV1	(SV2)			Always lighting	ON: light on OFF: light off •When abnormality occurs, check display.
1	10000000	Indoor unit check status	No.1 unit check	No.2 unit check	No.3 unit check	No.4 unit check	No.5 unit check	No.6 unit check	No.7 unit check	No.8 unit check	Light on at time of abnormality
2	01000000	Protection input	High pressure abnormality	Superheat due to low discharge temperature	Compressor shell temperature abnormality	TH4 abnormality	TH3 abnormality	Outdoor fan rotation frequency abnormality	TH7 abnormality	TH8 abnormality	
3	11000000	Protection input	Heat sink overheating	Compressor over current interception	Voltage abnormality	Insufficient refrigerant amount abnormality	Current sensor/primary current abnormality	63LS abnormality	63HS abnormality	start over current interception abnormality delay	Display detected microprocessor protection or abnormality
4	00100000	Protection input	Abnormality in the number of indoor units	Address double setting abnormality	Indoor unit capacity error	Over capacity	Indoor unit address error	Outdoor unit address error	Current sensor open/short	serial communication abnormality (outdoor unit)	
5	10100000	Abnormality delay display 1	High pressure abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	Display all abnormalities remaining in abnormality delay
6	01100000	Abnormality delay display 2	Heat sink overheating delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
7	11100000	Abnormality delay display 3	63LS abnormality delay	TH2 abnormality delay	4-way valve abnormality delay	TH4 abnormality delay	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
8	00010000	Abnormality delay history 1	High pressure abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	Display all abnormalities remaining in abnormality delay
9	10010000	Abnormality delay history 2	Heat sink overheating delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
10	01010000	Abnormality delay history 3	63LS abnormality delay	TH2 abnormality delay	4-way valve abnormality delay	TH4 abnormality delay	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
11	11010000	Abnormality code history 1 (the latest)	Abnormality code history 1								
12	00110000	Abnormality code history 2									
13	10110000	Abnormality code history 3									
14	01110000	Abnormality code history 4									
15	11110000	Abnormality code history 5									
16	00001000	Abnormality code history 6	Alternating display of addresses 0000-9999 and abnormality code (including abnormality delay code)								• Display abnormalities up to present (including abnormality terminals) • History record in 1 is the latest; records become older in sequence; history record in 10 is the oldest.
17	10001000	Abnormality code history 7									
18	01001000	Abnormality code history 8									
19	11001000	Abnormality code history 9									
20	00101000	Abnormality code history 10 (the oldest)									
21	10101000	Cumulative time	0-9999 (unit: 1 hour)								
22	01101000	Cumulative time	0-9999 (unit: 10 hour)								
23	11101000	Outdoor unit operation display	Compressor energizing	Compressor operating prohibition	Compressor in operation	Abnormality detection					Display of cumulative compressor operating time
24	00011000	Indoor unit operation mode	No.1 unit mode	No.2 unit mode	No.3 unit mode	No.4 unit mode	No.5 unit mode	No.6 unit mode	No.7 unit mode	No.8 unit mode	Light ON/Light OFF Cooling: light on, Heating: light blinking Stop fan: light off
25	10011000	Indoor unit operation display	No.1 unit operation	No.2 unit operation	No.3 unit operation	No.4 unit operation	No.5 unit operation	No.6 unit operation	No.7 unit operation	No.8 unit operation	Thermo ON: light on Thermo OFF: light off

No.			SW1 setting		Display mode		Display on the LED1, 2 (display data)								Notes									
			12345678				1		2		3		4		5		6		7		8			
26			01011000		Capacity code (No. 1 indoor unit)		0-255																•Display of indoor unit capacity code •The No. 1 unit will start from the M-NET address with the lowest number	
27			11011000		Capacity code (No. 2 indoor unit)																			
28			00111000		Capacity code (No. 3 indoor unit)																			
29			10111000		Capacity code (No. 4 indoor unit)																			
30			01111000		Capacity code (No. 5 indoor unit)																			
31			11111000		IC1 operation mode		STOP														•Display of indoor unit operating mode			
32			00000100		IC2 operation mode																			
33			10000100		IC3 operation mode																			
34			01000100		IC4 operation mode																			
35			11000100		IC5 operation mode																			
36			00100100		OC operation mode		Compressor ON/OFF CN3N1-3 input		Heating/Cooling CN3N1-2 input		Fan		Cooling thermo-ON Abnormal/normal CN3S1-2 input		Cooling thermo-OFF DEFROST/NO CN3D1-3 input		Heating thermo-ON Refrigerant pull back/no CN3D1-2 input		Heating thermo-OFF Excitation current/no 3-min. delay/no		Light on/light off Input: light off No input: light on Display of communication demand capacity			
37			10100100		External connection status																			
38			01100100		Communication demand capacity																			
39			11100100		Number of compressor ON/OFF																			
40			00010100		Compressor operating current																			
41			10010100		Input current of outdoor unit		Thermo-ON operating time		0-999.9 (Arms)		0-999.9 (Arms)		0-999.9 (Arms)		0-999.9 (Arms)		0-999.9 (Arms)		0-999.9 (Arms)		0-999.9 (Arms)			
42			01010100																					
43			11010100		Total capacity of thermo-ON																			
44			00110100		Number of indoor units																			
45			10110100		DC bus voltage																			
46			01110100		State of LEV control		Td over heat prevention		SHd decrease prevention		Min. Sj correction depends on Td		Min. Sj correction depends on SHd		LEV opening correction depends on Pd		LEV opening correction depends on Td		Correction of high compression ratio prevention		Freeze prevention control at the beginning of SHd			
47			11110100		State of compressor frequency control 1		Condensing temperature limit control		Compressor temperature control				Discharge temp. (heating) backup control		Pd abnormality control (heating)		Pd Back up control (heating)				Display active compressor frequency control			
48			00001100		State of compressor frequency control 2		Heat sink over heat prevention control		Secondary current control		Input current control				Frequency restrain of receipt voltage change		Low pressure decrease prevention		Hz-up inhibit control at the beginning of SHd					
49			10001100		Protection input		63LS abnormality		HIC abnormality				Frozen protection		4-way valve disconnection abnormality		Delay caused by blocked valve in cooling mode		TH6 abnormality		Power module abnormality			
50			01001100		The second current value when microprocessor of POWER BOARD abnormality is detected		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]		0-999.9[Arms]			
51			11001100		Heat sink temperature when microprocessor of POWER BOARD abnormality is detected																			

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
52	00101100	Outdoor LEV-A opening pulse	0-2000 (pulse)								Display of opening pulse of outdoor LEV
53	10101100	Outdoor LEV-A opening pulse abnormality delay									
54	01101100	Outdoor LEV-A opening pulse abnormality									
55	11101100	Outdoor LEV-B opening pulse									
56	00011100	Outdoor LEV-B opening pulse abnormality delay									
57	10011100	Outdoor LEV-B opening pulse abnormality	-99.9-999.9 (PSIG)								Display of data from sensor and thermistor
58	01011100	63LS (Low pressure)									
59	11011100	63LS abnormality delay									
60	00111100	63 LS abnormality									
61	10111100	TH2 (Hic pipe)									
62	01111100	TH2(HIC) abnormality delay	-99.9-999.9 (°F)								Display of actual operating frequency
63	11111100	TH2 (HIC) abnormality									
64	00000010	Operational frequency									
65	10000010	Target frequency									
66	01000010	Outdoor fan control step number									
69	10100010	IC1 LEV Opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
70	01100010	IC2 LEV Opening pulse									
71	11100010	IC3 LEV Opening pulse									
72	00010010	IC4 LEV Opening pulse									
73	10010010	IC5 LEV Opening pulse									
74	01010010	High pressure sensor (Pt)	-99.9-999.9 (PSIG)								Display detected data of outdoor unit sensors and thermistors
75	11010010	TH4(Compressor)Td data									
76	00110010	TH6(Suction pipe)ET data									
77	10110010	TH7(Ambient) data									
78	01110010	TH3(Outdoor liquid pipe) data									
80	00001010	TH8(Heat sink) data	-99.9-999.9 (°F)								Display detected data of indoor unit thermistor
81	10001010	IC1 TH23 (Gas)									
82	01001010	IC2 TH23 (Gas)									
83	11001010	IC3 TH23 (Gas)									
84	00101010	IC4 TH23 (Gas)									
85	10101010	IC5 TH23 (Gas)	-99.9-999.9 (°F) (When indoor unit is not connected, it is displayed as0.)								

No.		SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
				1	2	3	4	5	6	7	8	
86	01101010		IC1 TH22 (Liquid)	-99.9~999.9 (°F) (When the indoor unit is not connected, it is displayed as 0.)								Display detected data of indoor unit thermistors
87	11101010		IC2 TH22 (Liquid)									
88	00011010		IC3 TH22 (Liquid)									
89	10011010		IC4 TH22 (Liquid)									
90	01011010		IC5 TH22 (Liquid)									
91	11011010		IC1 TH21 (Intake)									
92	00111010		IC2 TH21 (Intake)									
93	10111010		IC3 TH21 (Intake)									
94	01111010		IC4 TH21 (Intake)									
95	11111010		IC5 TH21 (Intake)									
96	00000110		Outdoor SC (cooling)	-99.9~999.9 (°C) -2~4								Display of outdoor subcool (SC) data Display of target subcool step data
97	10000110		Target subcool step									
98	01000110		IC1 SC/SH	-99.9~999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
99	11000110		IC2 SC/SH									
100	00100110		IC3 SC/SH									
101	10100110		IC4 SC/SH									
102	01100110		IC5 SC/SH									
103	11100110		Discharge superheat (SHd)	-99.9~999.9 (°C) Pdm (0.0~30.0) (kgf/cm²) ETm (-2.0~23.0) (°C) SCm (0.0~20.0) (°C)								Display of outdoor discharge superheat (SHd) data
105	10010110		Target P display (heating) kgfF									
106	01010110		Target ET display (cooling)									
107	11010110		Target outdoor SC (cooling)									
108	00110110		Target indoor SC/SH (IC1)	SCm/SHm (0.0~20.0) (°C)								Display of all control target data
109	10110110		Target indoor SC/SH (IC2)									
110	01110110		Target indoor SC/SH (IC3)									
111	11110110		Target indoor SC/SH (IC4)									
112	00001110		Target indoor SC/SH (IC5)									
113	10001110		Indoor unit/heat status (IC9-12)	No.9 unit check	No. 10 unit check	No.11 unit check	No.12 unit check					Light on at time of abnormality COOL/DRY: light on HEAT: light blinking FAN/STOP: light off
114	01001110		Indoor unit operation mode (IC9-12)	No.9 unit mode	No. 10 unit mode	No.11 unit mode	No. 12 unit mode					
115	11001110		Indoor unit operation display (IC9-12)	No.9 unit operation	No. 10 unit operation	No.11 unit operation	No. 12 unit operation					Thermo-ON: light on Thermo-OFF: light off
116	00101110		IC9 operation mode	STOP	Fan	Cooling Thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF			
117	10101110		IC10 operation mode									
118	01101110		IC11 operation mode									
119	11101110		IC12 operation mode	SCm/SHm (0.0~20.0) (°C)								Display of indoor unit operation mode
120	00011110		Target indoor SC/SH (IC9)									
121	10011110		Target indoor SC/SH (IC10)									
122	01011110		Target indoor SC/SH (IC11)									
123	11011110		Target indoor SC/SH (IC12)									
124	00111110		IC9 LEV opening pulse abnormality delay	0~2000 (pulse)								Display of all control target data
125	10111110		IC10 LEV opening pulse abnormality delay									
126	01111110		IC11 LEV opening pulse abnormality delay									
127	11111110		IC12 LEV opening pulse abnormality delay									





No.		SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
				1	2	3	4	5	6	7	8	
128	00000001		Actual frequency of abnormality delay	0-255 (Hz)								Display of actual frequency at time of abnormality delay
129	10110001		Fan step number at time of abnormality delay	0-15								Display of fan step number at time of abnormality delay
131	11000001		IC1 LEV opening pulse abnormality delay	0-2000 (pulse)								Delay of opening pulse of indoor LEV at time of abnormality delay
132	00100001		IC2 LEV opening pulse abnormality delay									
133	10100001		IC3 LEV opening pulse abnormality delay									
134	01100001		IC4 LEV opening pulse abnormality delay									
135	11100001		IC5 LEV opening pulse abnormality delay									
136	00010001		High pressure sensor data at time of abnormality delay kgf/cm2	-99.9-999.9 (PSIG)								Display of data from High pressure sensor, all thermistors, and SC/SH at time of abnormality delay
137	10010001		TH4 (Compressor) sensor data at time of abnormality delay °C	-99.9-999.9 (°F)								
138	01010001		TH6 (Suction pipe) sensor data at time of abnormality delay °C									
139	11010001		TH3 (Outdoor liquid pipe) sensor data at time of abnormality delay °C									
140	00110001		TH8 (Heat sink) sensor data at time of abnormality delay °C									
141	10110001		OC SC (cooling) at time of abnormality delay °C	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								
142	01110001		IC1 SC/SH at time of abnormality delay °C									
143	11110001		IC2 SC/SH at time of abnormality delay °C									
144	00001001		IC3 SC/SH at time of abnormality delay °C									
145	10001001		IC4 SC/SH at time of abnormality delay °C									
146	01001001		IC5 SC/SH at time of abnormality delay °C									
147	11001001		IC9 SC/SH at time of abnormality delay °C									
148	00100001		IC10 SC/SH at time of abnormality delay °C									
149	10101001		IC11 SC/SH at time of abnormality delay °C									
150	01101001		IC12 SC/SH at time of abnormality delay °C									

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
151	11101001	IC9 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
152	00011001	IC10 LEV opening pulse at time of abnormality									
153	10011001	IC11 LEV opening pulse at time of abnormality									
154	01011001	IC12 LEV opening pulse at time of abnormality									
155	11011001	IC9 SC/SH at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality
156	00111001	IC10 SC/SH at time of abnormality									
157	10111001	IC11 SC/SH at time of abnormality									
158	01111001	IC12 SC/SH at time of abnormality									
159	11111001	IC9 Capacity code	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number
160	0000101	IC10 Capacity code									
161	10000101	IC11 Capacity code									
162	01000101	IC12 Capacity code									
163	11000101	IC9 SC/SH	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
164	00100101	IC10 SC/SH									
165	10100101	IC11 SC/SH									
166	01100101	IC12 SC/SH									
170	01010101	ROM version monitor	0.00-99.99 (ver)								Display of version data of ROM
171	11010101	ROM type									Display of ROM type
172	00110101	Check sum mode	0000-FFFF								Display of check sum code of ROM
173	10110101	IC9 TH23 (Gas)	-99.9-999.9 (°F)								Display detected data of indoor unit thermistors
174	01110101	IC10 TH23 (Gas)									
175	11110101	IC11 TH23 (Gas)									
176	00001101	IC12 TH23 (Gas)									
177	10001101	IC9 TH22 (Liquid)									
178	01001101	IC10 TH22 (Liquid)									
179	11001101	IC11 TH22 (Liquid)									
180	00101101	IC12 TH22 (Liquid)									
181	10101101	Backup heating determination value "a"									
182	01101101	Backup heating determination value "b"									
183	11101101	Backup heating determination value "c"									
184	00011101	Backup heating determination value "d"									
185	10011101	IC9 TH21 (Intake)									
186	01011101	IC10 TH21 (Intake)									
187	11011101	IC11 TH21 (Intake)									
188	00111101	IC12 TH21 (Intake)									



No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
189	10111101	History of voltage error (U9/4220)	-	-	PAM error	Converter Fault	Power synchronization signal error	L1 open phase error	Under voltage error	Over voltage error	
192	00000011	Actual frequency of abnormality	0-255 (Hz)								Display of actual frequency at time of abnormality
193	10000011	Fan step number at time of abnormality	0-15								Display of fan step number at time of abnormality
195	11000011	IC1 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
196	00100011	IC2 LEV opening pulse at time of abnormality									
197	10100011	IC3 LEV opening pulse at time of abnormality									
198	01100011	IC4 LEV opening pulse at time of abnormality									
199	11100011	IC5 LEV opening pulse at time of abnormality									
200	00010011	High pressure sensor data at time of abnormality	-99.9-999.9 (PSIG)								Display of data from High pressure sensor, all thermistors, and SC/SH at time of abnormality.
201	10010011	TH4 (Compressor) sensor data at time of abnormality	-99.9-999.9 (°F)								
202	01010011	TH6 (Suction pipe) sensor data at time of abnormality									
203	11010011	TH3 (Outdoor liquid pipe) sensor data at time of abnormality									
204	00110011	TH8 (Heat sink) sensor data at time of abnormality									
205	10110011	OC SC (cooling) at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality
206	01110011	IC1 SC/SH at time of abnormality									
207	11110011	IC2 SC/SH at time of abnormality									
208	00001011	IC3 SC/SH at time of abnormality									
209	10001011	IC4 SC/SH at time of abnormality									
210	01001011	IC5 SC/SH at time of abnormality	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number
211	11001011	IC6 Capacity code									
212	00101011	IC7 Capacity code									
213	10101011	IC8 Capacity code									
214	01101011	IC6 operation mode	STOP	Fan	Cooling thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF			Display of indoor unit operation mode
215	11101011	IC7 operation mode									
216	00011011	IC8 operation mode									

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
217	10011011	IC6 LEV opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
218	01011001	IC7 LEV opening pulse									
219	11011001	IC8 LEV opening pulse									
220	00111011	IC6 TH23 (Gas)									
221	10111011	IC7 TH23 (Gas)	-99.9-999.9 (°F)								Display detected data of indoor unit thermistor
222	01111011	IC8 TH23 (Gas)									
223	11111011	IC6 TH22 (liquid)									
224	00000111	IC7 TH22 (liquid)									
225	10000111	IC8 TH22 (liquid)									
226	01000111	IC6 TH21 (intake)									
227	11000111	IC7 TH21 (intake)									
228	00100111	IC8 TH21 (intake)									
229	10100111	IC6 SC/SH	-99.9-999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
230	01100111	IC7 SC/SH									
231	11100111	IC8 SC/SH									
232	00010111	Target indoor SC/SH (IC6)									
233	10010111	Target indoor SC/SH (IC7)	SCm/SHm (0.0-20.0) (°C)								Display of all control target data
234	01010111	Target indoor SC/SH (IC8)									
235	11010111	IC6 LEV opening pulse abnormality delay									
236	00110111	IC7 LEV opening pulse abnormality delay									
237	10110111	IC8 LEV opening pulse abnormality delay	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality delay
238	01110111	IC6 SC/SH at time of abnormality delay									
239	11110111	IC7 SC/SH at time of abnormality delay									
240	00001111	IC8 SC/SH at time of abnormality delay									
241	10001111	IC6 LEV opening pulse at time of abnormality	-99.9-999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality delay
242	01001111	IC7 EV opening pulse at time of abnormality									
243	11001111	IC8 LEV opening pulse at time of abnormality									
244	00101111	IC6 SC/SH at time of abnormality									
245	10101111	IC7 SC/SH at time of abnormality	-99.9-999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality delay
246	01101111	IC8 SC/SH at time of abnormality									
250	01011111	IC9 LEV opening pulse									
251	11011111	IC10 LEV opening pulse									
252	00111111	IC11 LEV opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
253	10111111	IC12 LEV opening pulse									

This chapter provides an introduction to electrical wiring for the CITY MULTI-S series, together with notes concerning power wiring, wiring for control (transmission wires and remote controller wires), and the frequency converter.

### 9-1. OVERVIEW OF POWER WIRING

- (1) Use a separate power supply for the outdoor unit and indoor unit.
- (2) Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
- (3) The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10 %.
- (4) Specific wiring requirements should adhere to the wiring regulations of the region.
- (5) Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
- (6) Install an earth longer than other cables.

**⚠ Warning:**

- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.


**⚠ Caution:**

- Some installation site may require attachment of an earth leakage breaker. If no earth leakage breaker is installed, it may cause an electric shock.
- Do not use anything other than breaker and fuse with correct capacity. Using fuse and wire or copper wire with too large capacity may cause a malfunction of unit or fire.
- Be sure to install N-Line. Without N-Line, it could cause damage to the unit.

### 9-2. WIRING OF MAIN POWER SUPPLY AND EQUIPMENT CAPACITY

#### 9-2-1. Wiring diagram for main power supply

##### ■ Schematic Drawing of Wiring



## 9-2-2. Cross section area of Wire for Main Power and ON/OFF capacities PUMY-P60NKMU1(-BS)

### Thickness of Wire for Main Power Supply and On/Off Capacities

Model		Power Supply	Minimum Wire Thickness (AWG [mm <sup>2</sup> ])		Breaker for Wiring*1	Breaker for Current Leakage	Minimum circuit ampacity	Maximum rating of over current protector device
			Main Cable*2	Ground				
Outdoor Unit	P60	208/230 VAC, 60 Hz	AWG8 [8.4]	AWG8 [8.4]	40 A	40 A 30 mA 0.1 sec. or less	36 A	42 A
Indoor Unit		208/230 VAC, 60 Hz	Refer to installation manual of indoor unit.					

\*1. A breaker with at least 3.0 mm [1/8 inch] contact separation in each poles shall be provided.  
Use non-fuse breaker (NF) or earth leakage breaker (NV).

\*2. Use copper supply wires. Use the electric wires over the rating voltage 300 V.

Total operating current of the indoor unit	Minimum wire thickness (AWG [mm <sup>2</sup> ])			Ground-fault interrupter *1	Local switch (A)		Breaker for wiring (NFB)
	Main Cable	Branch	Ground		Capacity	Fuse	
F0 = 15 A or less *2	14/2.1	14/2.1	2.1/14	15 A current sensitivity *3	15	15	15
F0 = 20 A or less *2	12/3.3	12/3.3	12/3.3	20 A current sensitivity *3	20	20	20
F0 = 30 A or less *2	10/5.5	10/5.5	10/5.3	30 A current sensitivity *3	30	30	30

Apply to IEC61000-3-3 about max. permissive system impedance.

\*1 The Ground-fault interrupter should support inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

\*2 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = {V1 × (Quantity of Type1)/C} + {V1 × (Quantity of Type2)/C} + {V1 × (Quantity of Type3)/C} + {V1 × (Quantity of Others)/C}

Indoor unit		V1	V2
Type 1	PKFY-P-NHMu, PKFY-P-NKMu, PEFY-P-NMSU, PLFY-P-NEMU, PLFY-EP-NEMU, PMFY-P-NBMU, PCFY-P-NKMu	19.8	2.4
Type 2	PEFY-P-NMAU, PVFY-P-NAMU	38.0	1.6
Type 3	PKFY-P-NBMU, PLFY-P-NCMU	3.5	2.4
Others	PFFY-P-NEMU, PFFY-P-NRMU, PDFY-P-NMU, PEFY-P-NMHU	0.0	0.0

C : Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.

<Example of "F2" calculation>

\* Condition PEFY-NMSU × 4 + PEFY-NMAU × 1, C = 8 (refer to right sample chart)

F2 = 19.8 × 4/8 + 38 × 1/8

= 14.65


→ 16 A breaker (Tripping current = 8 × 16 A at 0.01 s)

\* 3 Current sensitivity is calculated using the following formula.

G1 = V2 × (Quantity of Type1) + V2 × (Quantity of Type2) + V2 × (Quantity of Type3) + V2 × (Quantity of Others)  
+ V3 × (Wire length [km])

G1	Current sensitivity
30 or less	30 mA 0.1 sec or less
100 or less	100 mA 0.1 sec or less

Wire thickness (AWG/mm <sup>2</sup> )	V3
14/2.1	48
12/3.3	56
10/5.3	66



1. Use a separate power supply for the outdoor unit and indoor unit.
2. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
3. The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops.  
Make sure the power-supply voltage does not drop more than 10%.
4. Specific wiring requirements should adhere to the wiring regulations of the region.
5. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For exam-

### 9-3. DESIGN FOR CONTROL WIRING

Please note that the types and numbers of control wires needed by the CITY MULTI-S series depend on the remote controllers and whether they are linked with the system or not.

#### 9-3-1. Selection number of control wires

		M-NET remote controller
Use		Remote controller used in system control operations. • Group operation involving different refrigerant systems. • Linked operation with upper control system.
Remote controller → indoor unit		2-core wire (non-polar)
Transmission wires	Wires connecting → indoor units	
	Wires connecting → indoor units with outdoor unit	
	Wires connecting → outdoor units	

### 9-4. WIRING TRANSMISSION CABLES

#### 9-4-1. Types of control cables

1. Wiring transmission cables
  - Types of transmission cables: Shielding wire CVVS, CPEVS or MVVS
  - Cable diameter: More than AWG 16 [1.25 mm<sup>2</sup>]
  - Maximum wiring length: Within 656 ft [200 m]

#### 2. M-NET Remote control cables

Kind of remote control cable	Shielding wire (2-core) CVVS, CPEVS or MVVS
Cable diameter	AWG 20 to AWG 16 [0.5 to 1.25 mm <sup>2</sup> ]
Remarks	When 10 m is exceeded, use a cable with the same specifications as transmission line wiring.

#### 3. MA Remote control cables

Kind of remote control cable	Sheathed 2-core cable (unshielded) CVV
Cable diameter	AWG 22 to AWG 16 [0.3 to 1.25 mm <sup>2</sup> ] (AWG 18 to AWG 16 [0.75 to 1.25 mm <sup>2</sup> ])*
Remarks	Within 656 ft [200 m]

\* Connected with simple remote controller.

#### 9-4-2. Wiring examples

- Controller name, symbol and allowable number of controllers.

Name	Symbol	Allowable number of controllers	
Outdoor unit controller	OC	—	
Indoor unit controller	M-IC	PUMY-P60	1 to 12 units per 1 OC
Remote controller	RC	M-NET RC	Maximum of 10 controllers for 1 OC
		MA-RC	Maximum of 2 per group


Note that the number of connectable units may be limited by some conditions such as an indoor unit's capacity or each unit's equivalent power consumption. (Refer to DATA BOOK.)

## 9-5. SYSTEM SWITCH SETTING

In order to identify the destinations of signals to the outdoor units, indoor units, and remote controller of the MULTI-S series, each microprocessor must be assigned an identification number (address). The addresses of outdoor units, indoor units, and remote controller must be set using their settings switches. Please consult the installation manual that comes with each unit for detailed information on setting procedures.

## 9-6. EXAMPLE EXTERNAL WIRING DIAGRAM FOR A BASIC SYSTEM

■ Example of system when using a M-NET controller



## 9-7. METHOD FOR OBTAINING ELECTRICAL CHARACTERISTICS WHEN A CAPACITY AGREEMENT IS TO BE SIGNED WITH AN ELECTRIC POWER COMPANY

The electrical characteristics of connected indoor unit system for air conditioning systems, including the MULTI-S series, depend on the arrangement of the indoor and outdoor units.

First read the data on the selected indoor and outdoor units and then use the following formulas to calculate the electrical characteristics before applying for a capacity agreement with the local electric power company.

### 9-7-1. Obtaining the electrical characteristics of a CITY MULTI-S series system

#### (1) Procedure for obtaining total power consumption

	Page numbers in this technical manual	Power consumption
Total power consumption of each indoor unit	See the technical manual of each indoor unit	①
Power consumption of outdoor unit*	Standard capacity diagram— Refer to 4-3.	②
Total power consumption of system	See the technical manual of each indoor unit	①+② <kW>

\*The power consumption of the outdoor unit will vary depending on the total capacity of the selected indoor units.

#### (2) Method of obtaining total current

	Page numbers in this technical manual	Subtotal
Total current through each indoor unit	See the technical manual of each indoor unit	①
Current through outdoor unit*	Standard capacity diagram— Refer to 4-3.	②
Total current through system	See the technical manual of each indoor unit	①+② <A>

The current through the outdoor unit will vary depending on the total capacity of the selected indoor units.

#### (3) Method of obtaining system power factor

Use the following formula and the total power and current obtained in parts ① and ② on the above tables to calculate the system power factor.

$$\text{System power factor} = \frac{(\text{Total system power consumption})}{(\text{Total system current} \times \text{voltage})} \times 100 \%$$


### 9-7-2. Applying to an electric power company for power and total current

Calculations should be performed separately for heating and cooling employing the same methods; use the largest resulting value in your application to the electric power company.

## 10-1. REFRIGERANT PIPING SYSTEM

**Line-Branch Method**

Connection Examples  
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	$A+B+C+a+b+c+d \leq 492 \text{ ft [150 meters]}$
	Farthest Piping Length (L)	$A+B+C+d \leq 262 \text{ ft [80 meters]}$
	Farthest Piping Length After First Branch (L)	$B+C+d \leq 98 \text{ ft [30 meters]}$
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 meters] (If the outdoor unit is lower, 131 ft [40 meters])
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 meters]

■ **Selecting the Refrigerant Branch Kit**

Use an optional branch piping kit (CMY-Y62-G-E).

■ **Select Each Section of Refrigerant Piping**

- (1) Section From Outdoor Unit to First Branch (A)  
 (2) Sections From Branch to Indoor Unit (a,b,c,d)  
 (3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)  
 (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

Model	Piping Diameter (inch[mm])
PUMY-P60	Liquid Line $3/8 [\phi 9.52]$
	Gas Line $3/4 [\phi 19.05]$

Model number	Piping Diameter (inch[mm])
18 or lower	Liquid Line $1/4 [\phi 6.35]$
	Gas Line $1/2 [\phi 12.7]$
24 to 54	Liquid Line $3/8 [\phi 9.52]$
	Gas Line $5/8 [\phi 15.88]$
72	Liquid Line $3/8 [\phi 9.52]$
	Gas Line $3/4 [\phi 19.05]$

- (3) Refrigerant Piping Diameter In Section From Branch to Branch

Liquid Line (inch[mm])	Gas Line (inch[mm])
$3/8 [\phi 9.52]$	$3/4 [\phi 19.05]$

■ **Additional refrigerant charge**

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

**Calculation of additional refrigerant charge**

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.2 lb [0.1 kg], round up the calculated additional refrigerant charge.  
(For example, if the calculated charge is 13.2 lb [6.01 kg], round up the charge to 13.4 lb [6.1 kg].)

<Additional Charge>

**Calculation of refrigerant charge**

Pipe size Liquid pipe $\phi 6.35$ [ft] $\times 0.29$ [oz/ft] (m) $\times 27.0$ (g/m)	+	Pipe size Liquid pipe $\phi 9.52$ [ft] $\times 0.75$ [oz/ft] (m) $\times 70.0$ (g/m)	+	Total capacity of connected indoor units – 27 kBTU/h 28 – 54 kBTU/h 55 – 62 kBTU/h	Amount for the indoor units 53 oz (1.5 kg) 88 oz (2.5 kg) 106 oz (3.0 kg)
--	---	--	---	--	---

**Included refrigerant amount when shipped from the factory**

Included refrigerant amount
11 LBS. 4 OZ. (5.1 kg)

<Example>

Outdoor model : P60

Indoor 1 : P24 (24 kBTU/h)

2 : P15 (15 kBTU/h)

3 : P08 (8 kBTU/h)

4 : P06 (6 kBTU/h)

A :  $\phi 9.52$  66 ft [20 m]

B :  $\phi 9.52$  16 ft [5 m]

C :  $\phi 9.52$  16 ft [5 m]

a :  $\phi 9.52$  49 ft [15 m]

b :  $\phi 6.35$  33 ft [10 m]

c :  $\phi 6.35$  33 ft [10 m]

d :  $\phi 6.35$  66 ft [20 m]

At the conditions  
below:

The total length of each liquid line is as follows:

[3/8"]  $\phi 9.52$  :  $A + B + C + a = 20 + 5 + 5 + 15 = 147 \text{ ft [45 m]}$

[1/4"]  $\phi 6.35$  :  $b + c + d = 10 + 10 + 20 = 132 \text{ ft [40 m]}$

The total capacity of connected indoor unit is as follows:

24 + 15 + 08 + 06 = 53


<Calculation example>

Additional refrigerant charge

$132 \text{ ft} \times 0.29 \text{ oz} + 147 \text{ ft} \times 0.75 \text{ oz} + 88 \text{ oz} = 237 \text{ oz}$   $\left[ 40 \times \frac{27.0}{1000} + 45 \times \frac{70.0}{1000} + 2.5 = 6.8 \text{ kg (rounded up)} \right]$



**Header-Branch Method**  
Connection Examples  
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	$A+a+b+c+d \leq 492 \text{ ft [150 meters]}$
	Farthest Piping Length (L)	$A+d \leq 262 \text{ ft [80 meters]}$
	Farthest Piping Length After First Branch (l)	d is 100 ft [30 meters]
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 meters] (If the outdoor unit is lower, 131 ft [40 meters])
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 meters]

■ **Selecting the Refrigerant Branch Kit**

Please select branching kit, which is sold separately, from the table below.  
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

Branch header (4 branches)	Branch header (8 branches)
CMY-Y64-G-E	CMY-Y68-G-E

■ **Select Each Section of Refrigerant Piping**

- (1) Section From Outdoor Unit to First Branch (A)  
(2) Sections From Branch to Indoor Unit (a,b,c,d)
- Each Section of Piping

Select the size from the table to the right.

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)

Model	Piping Diameter (inch[mm])
PUMY-P60	Liquid Line 3/8 [φ9.52]
	Gas Line 3/4 [φ19.05]

- (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

Model number	Piping Diameter (inch[mm])
18 or lower	Liquid Line 1/4 [φ6.35]
	Gas Line 1/2 [φ12.7]
24 to 54	Liquid Line 3/8 [φ9.52]
	Gas Line 5/8 [φ15.88]
72	Liquid Line 3/8 [φ9.52]
	Gas Line 3/4 [φ19.05]

- (3) Refrigerant Piping Diameter In Section From Branch to Branch

Liquid Line (inch [mm])	Gas Line (inch [mm])
3/8 [φ9.52]	3/4 [φ19.05]

■ **Additional refrigerant charge**

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

**Calculation of additional refrigerant charge**

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.2 lb [0.1 kg], round up the calculated additional refrigerant charge.  
(For example, if the calculated charge is 13.2 lb [6.01 kg], round up the charge to 13.4 lb [6.1 kg].)

<Additional Charge>

**Calculation of refrigerant charge**

Pipe size Liquid pipe	Pipe size Liquid pipe	Total capacity of connected indoor units	Amount for the indoor units
ø6.35	ø9.52	– 27 kBTU/h	53 oz (1.5 kg)
[ft] × 0.29 [oz/ft] (m) × 27.0 (g/m)	[ft] × 0.75 [oz/ft] (m) × 70.0 (g/m)	28 – 54 kBTU/h	88 oz (2.5 kg)
		55 – 62 kBTU/h	106 oz (3.0 kg)

**Included refrigerant amount when shipped from the factory**

Included refrigerant amount
11 LBS. 4 OZ. (5.1 kg)

<Example>

Outdoor model : P60  
Indoor 1 : P24 (24 kBTU/h)  
2 : P15 (15 kBTU/h)  
3 : P08 (8 kBTU/h)  
4 : P06 (6 kBTU/h)

A : ø9.52 66 ft [20 m]  
B : ø9.52 16 ft [5 m]  
C : ø9.52 16 ft [5 m]  
a : ø9.52 49 ft [15 m]  
b : ø6.35 33 ft [10 m]  
c : ø6.35 33 ft [10 m]  
d : ø6.35 66 ft [20 m]

At the conditions below:

The total length of each liquid line is as follows:  
[3/8"] ø9.52 :  $A + B + C + a = 20 + 5 + 5 + 15 = 147 \text{ ft [45 m]}$   
[1/4"] ø6.35 :  $b + c + d = 10 + 10 + 20 = 132 \text{ ft [40 m]}$

The total capacity of connected indoor unit is as follows:  
 $24 + 15 + 08 + 06 = 53$


<Calculation example>

Additional refrigerant charge

$$132 \text{ ft} \times 0.29 \text{ oz} + 147 \text{ ft} \times 0.75 \text{ oz} + 88 \text{ oz} = 237 \text{ oz} \left[ 40 \times \frac{27.0}{1000} + 45 \times \frac{70.0}{1000} + 2.5 = 6.8 \text{ kg (rounded up)} \right]$$

### Method of Combined Branching of Lines and Headers

Connection Examples  
(Connecting to 5 Indoor Units)



Permissible Length	Total Piping Length	A+B+C+a+b+c+d+e is 492 ft [150 meters]
	Farthest Piping Length (L)	A+B+b is 262 ft [80 meters]
	Farthest Piping Length After First Branch ( ℓ )	B+b is 100 ft [30 meters]
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	164 ft [50 meters] (If the outdoor unit is lower, 131 ft [40 meters] or less)
	High/Low Difference in Indoor/Indoor Section (h)	49 ft [15 meters]

#### ■ Selecting the Refrigerant Branch Kit

Please select branching kit, which is sold separately, from the table below.  
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

Branch Joint	Branch Header (4 branches)	Branch Header (8 branches)
CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E

#### ■ Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to First Branch (A)  
(2) Sections From Branch to Indoor Unit (a,b,c,d,e)  
(3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.

(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)

Model	Piping Diameter (in [mm])
PUMY-P60	Liquid Line 3/8 [ø9.52]
	Gas Line 3/4 [ø19.05]

(3) Refrigerant Piping Diameter In Section From Branch to Branch

Liquid Line (inch [mm])	Gas Line (inch [mm])
3/8 [ø9.52]	3/4 [ø19.05]

(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

Model number	Piping Diameter (in [mm])
18 or lower	Liquid Line 1/4 [ø6.35]
	Gas Line 1/2 [ø12.7]
24 to 54	Liquid Line 3/8 [ø9.52]
	Gas Line 5/8 [ø15.88]
72	Liquid Line 3/8 [ø9.52]
	Gas Line 3/4 [ø19.05]

#### ■ Additional refrigerant charge

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

##### Calculation of additional refrigerant charge

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.2 lb [0.1 kg], round up the calculated additional refrigerant charge.  
(For example, if the calculated charge is 13.2 lb [6.01 kg], round up the charge to 13.4 lb [6.1 kg].)

<Additional Charge>

##### Calculation of refrigerant charge

Pipe size	Pipe size	Total capacity of connected indoor units	Amount for the indoor units
Liquid pipe ø6.35	Liquid pipe ø9.52	- 27 kBTU/h	53 oz (1.5 kg)
[ft] × 0.29 [oz/ft] (m) × 27.0 (g/m)	[ft] × 0.75 [oz/ft] (m) × 70.0 (g/m)	28 - 54 kBTU/h	88 oz (2.5 kg)
		55 - 62 kBTU/h	106 oz (3.0 kg)

##### Included refrigerant amount when shipped from the factory

Included refrigerant amount
11 LBS. 4 OZ. (5.1 kg)

<Example>

Outdoor model : P60  
Indoor 1 : P24 (24 kBTU/h)  
2 : P15 (15 kBTU/h)  
3 : P08 (8 kBTU/h)  
4 : P06 (6 kBTU/h)

A : ø9.52 66 ft [20 m]  
B : ø9.52 16 ft [5 m]  
C : ø9.52 16 ft [5 m]  
a : ø9.52 49 ft [15 m]  
b : ø6.35 33 ft [10 m]  
c : ø6.35 33 ft [10 m]  
d : ø6.35 66 ft [20 m]

At the conditions below:

The total length of each liquid line is as follows:

[3/8"] ø9.52 : A + B + C + a = 20 + 5 + 5 + 15 = 147 ft [45 m]

[1/4"] ø6.35 : b + c + d = 10 + 10 + 20 = 132 ft [40 m]

The total capacity of connected indoor unit is as follows:

24 + 15 + 08 + 06 = 53

<Calculation example>

Additional refrigerant charge

132 ft × 0.29 oz + 147 ft × 0.75 oz + 88 oz = 237 oz  $\left[40 \times \frac{27.0}{1000} + 45 \times \frac{70.0}{1000} + 2.5 = 6.8 \text{ kg (rounded up)}\right]$

## 10-2. PRECAUTIONS AGAINST REFRIGERANT LEAKAGE


### 10-2-1. Introduction

R410A refrigerant of this air conditioner is non-toxic and non-flammable but leaking of large amount from an indoor unit into the room where the unit is installed may be deleterious. To prevent possible injury, the rooms should be large enough to keep the R410A concentration specified by ISO 5149-1 as follows.

Maximum concentration  
Maximum refrigerant concentration of R410A of a room is  $0.44\text{kg/m}^3$  [ $0.027\text{ lbs/ft}^3$ ] accordance with ISO 5149-1. To facilitate calculation, the maximum concentration is expressed in units of  $\text{kg/m}^3$  [ $\text{lbs/ft}^3$ ] (  $\text{kg}$  [ $\text{lbs}$ ] of R410A per  $\text{m}^3$  [ $\text{ft}^3$ ])

Maximum concentration of R410A:  $0.027\text{ lbs/ft}^3$  [ $0.44\text{ kg/m}^3$ ]

(ISO 5149-1)



### 10-2-2. Confirming procedure of R410A concentration

Follow (1) to (3) to confirm the R410A concentration and take appropriate treatment, if necessary.

- (1) Calculate total refrigerant amount by each refrigerant system. Total refrigerant amount is pre-charged refrigerant at ex-factory plus additional charged amount at field installation.**


Note:

When single refrigeration system consists of several independent refrigeration circuit, figure out the total refrigerant amount by each independent refrigerant circuit.


- (2) Calculate room volumes ( $\text{m}^3$ ) and find the room with the smallest volume**

The part with    represents the room with the smallest volume.


- (a) Situation in which there are no partitions**



- (b) There are partitions, but there are openings that allow the effective mixing of air.**



- (c) If the smallest room has mechanical ventilation apparatus that is linked to a household gas detection and alarm device, the calculations should be performed for the second smallest room.**



- (3) Use the results of calculations (1) and (2) to calculate the refrigerant concentration:**






$$\frac{\text{Total refrigerant in the refrigerating unit (lbs [kg])}}{\text{The smallest room in which an indoor unit has been installed (ft}^3\text{[m}^3\text{])}} \leq \text{Maximum concentration (lbs/ft}^3\text{[kg/m}^3\text{])}$$

Maximum concentration of R410A:  $0.027\text{ lbs/ft}^3$  [ $0.44\text{ kg/m}^3$ ]





If the calculation results do not exceed the maximum concentration, perform the same calculations for the larger second and third room, etc., until it has been determined that nowhere the maximum concentration will be exceeded.

**PUMY-P60NKMU1**  
**PUMY-P60NKMU1-BS**




Note: Turn OFF the power supply before disassembly.



OPERATING PROCEDURE	PHOTOS
<p><b>1. Removing the service panel and top panel</b></p> <p>(1) Remove 3 service panel fixing screws (5 × 12) and slide the hook on the right downward to remove the service panel.</p> <p>(2) Remove screws (3 for front, 3 for rear/5 × 12) of the top panel and remove it.</p>	<p><b>Photo 1</b></p> 
<p><b>2. Removing the fan motor (MF1, MF2)</b></p> <p>(1) Remove the service panel. (See Photo 1)</p> <p>(2) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)</p> <p>(3) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2.)</p> <p>(4) Disconnect the connectors, CNF1 and CNF2 on multi controller board in electrical parts box.</p> <p>(5) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)</p>	<p><b>Photo 2</b></p>  <p><b>Photo 3</b></p> 
<p><b>3. Removing the electrical parts box</b></p> <p>(1) Remove the service panel. (See Photo 1)</p> <p>(2) Remove the top panel. (See Photo 1)</p> <p>(3) Disconnect the connecting wire from terminal block. (See Photo 5)</p> <p>(4) Remove all the following connectors from outdoor multi controller circuit board;</p> <p>&lt;Diagram symbol in the connector housing&gt;</p> <ul style="list-style-type: none"> <li>• Fan motor (CNF1, CNF2)</li> <li>• Thermistor &lt;HIC pipe&gt; (TH2)</li> <li>• Thermistor &lt;Outdoor liquid pipe&gt; (TH3)</li> <li>• Thermistor &lt;Compressor&gt; (TH4)</li> <li>• Thermistor &lt;Suction pipe/Ambient, Outdoor&gt; (TH7/6)</li> <li>• High pressure switch (63H)</li> <li>• High pressure sensor (63HS)</li> <li>• Low pressure sensor (63LS)</li> <li>• 4-way valve (21S4)</li> <li>• Bypass valve (SV1)</li> <li>• Electronic expansion valve (CNLVA/CNLVB)</li> </ul> <p>Pull out the disconnected wire from the electrical parts box.</p> <p>(5) Remove the terminal cover and disconnect the compressor lead wire.</p> <p><b>Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.</b></p> <p><b>Figure 1</b></p> 	<p><b>Photo 4</b></p> 

From the previous page.





OPERATING PROCEDURE	PHOTOS
<p>(6) Remove 2 electrical parts box fixing screws (4 × 10) then detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.</p>	<p><b>Photo 5</b></p> 
<p><b>4. Removing the thermistor &lt;Suction pipe&gt; (TH6)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Disconnect the connectors, TH7/6 (red), on the multi controller circuit board in the electrical parts box.</li> <li>(4) Loosen the wire clamps on the back of electrical parts box.</li> <li>(5) Pull out the thermistor &lt;Suction pipe&gt; (TH6) from the sensor holder.</li> </ol> <p><b>Note:</b> When replacing thermistor &lt;Suction pipe&gt; (TH6), replace it together with thermistor &lt;Ambient&gt; (TH7) since they are combined together. Refer to procedure No.5 below to remove thermistor &lt;Ambient&gt; (TH7).</p>	<p><b>Photo 6</b></p>  <p><b>Photo 7</b></p> 
<p><b>5. Removing the thermistor &lt;Ambient&gt; (TH7)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box.</li> <li>(4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6.)</li> <li>(5) Pull out the thermistor &lt;Ambient&gt; (TH7) from the sensor holder.</li> </ol> <p><b>Note:</b> When replacing thermistor &lt;Ambient&gt; (TH7), replace it together with thermistor &lt;Suction pipe&gt; (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor &lt;Suction pipe&gt; (TH6).</p>	<p><b>Photo 8</b></p> 




OPERATING PROCEDURE	PHOTOS
<p><b>6. Removing the thermistors</b></p> <p><b>Thermistor &lt;HIC&gt; (TH2) and thermistor &lt;Compressor&gt; (TH4)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Disconnect the connectors, TH2 (black) and TH4 (white), on the multi controller board in the electrical parts box.</li> <li>(3) Pull out the thermistor &lt;HIC&gt; (TH2) and thermistor &lt;Compressor&gt; (TH4) from the sensor holder. (See Photo 9-1)</li> </ol> <p><b>Thermistor &lt;Outdoor pipe&gt; (TH3)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Disconnect the connector, TH3 (white), on the Multi controller board in the electrical parts box.</li> <li>(3) Loosen the clamp for the lead wire on the bottom of the electrical parts box.</li> <li>(4) Pull out the thermistor &lt;Outdoor pipe&gt; (TH3) from the sensor holder. (See Photo 9-2)</li> </ol>	<p><b>Photo 9-1</b></p>  <p><b>Photo 9-2</b></p> 
<p><b>7. Removing the 4-way valve coil (21S4)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> </ol> <p><b>[Removing the 4-way valve coil]</b></p> <ol style="list-style-type: none"> <li>(2) Remove 4-way valve coil fixing screw (M4 × 6).</li> <li>(3) Remove the 4-way valve coil by sliding the coil toward you.</li> <li>(4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box.</li> </ol>	<p><b>Photo 10</b></p> 
<p><b>8. Removing the 4-way valve</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Remove the electrical parts box (See photo 5)</li> <li>(4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7)</li> <li>(5) Remove 2 cover panel fixing screws (5 × 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4))</li> <li>(6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 × 12), then slide the cover panel (rear) upward to remove it. (See Photo 4) (The cover panel (rear) is fixed to the side panel (R) with 2 screws.)</li> <li>(7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.)</li> <li>(8) Remove the 4-way valve coil. (See Photo 10)</li> <li>(9) Recover refrigerant.</li> <li>(10) Remove the welded part of 4-way valve.</li> </ol> <p><b>Note 1: Recover refrigerant without spreading it in the air.</b></p> <p><b>Note 2: The welded part can be removed easily by removing the right side panel.</b></p> <p><b>Note 3: When installing the four-way valve, cover it with a wet cloth to prevent it from heating 248°F (120°C) or more, then braze the pipes so that the inside of pipes are not oxidized.</b></p>	



OPERATING PROCEDURE	PHOTOS
<p><b>9. Removing bypass valve coil (SV1) and bypass valve</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Remove the cover panel (front). (Refer to procedure 8(5))</li> <li>(4) Remove the cover panel (rear) (Refer to procedure 8(6))</li> <li>(5) Remove the side panel (R). (Refer to procedure 8 (7))</li> <li>(6) Remove the bypass valve coil fixing screw (M4 × 6).</li> <li>(7) Remove the bypass valve coil by sliding the coil upward.</li> <li>(8) Disconnect the connector SV1 (gray) on the multi controller circuit board in the electrical parts box.</li> <li>(9) Remove the electrical parts box. (See Photo 5)</li> <li>(10) Recover refrigerant.</li> <li>(11) Remove the welded part of bypass valve.</li> </ol> <p>Refer to the notes below.</p>	<p><b>Photo 11</b></p>  <p><b>Photo 12</b></p> 
<p><b>10. Removing the high pressure switch (63H) and high pressure sensor (63HS)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Remove the cover panel (front). (Refer to procedure 8(5))</li> <li>(4) Remove the cover panel (rear) (Refer to procedure 8(6))</li> <li>(5) Remove the side panel (R). (Refer to procedure 8 (7))</li> <li>(6) Pull out the lead wire of high pressure switch and high pressure sensor.</li> <li>(7) Remove the electrical parts box. (See Photo 5)</li> <li>(8) Recover refrigerant.</li> <li>(9) Remove the welded part of high pressure switch and high pressure sensor.</li> </ol> <p>Refer to the notes below.</p>	
<p><b>11. Removing the low pressure sensor (63LS)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Remove the cover panel (front). (Refer to procedure 8(5))</li> <li>(4) Remove the cover panel (rear) (Refer to procedure 8(6))</li> <li>(5) Remove the side panel (R). (Refer to procedure 8 (7))</li> <li>(6) Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box.</li> <li>(7) Remove the electrical parts box. (See Photo 5)</li> <li>(8) Recover refrigerant.</li> <li>(9) Remove the welded part of low pressure sensor.</li> </ol> <p>Refer to the notes below.</p>	<p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>1. Recover refrigerant without spreading it in the air.</li> <li>2. The welded part can be removed easily by removing the right side panel.</li> <li>3. When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized; <ul style="list-style-type: none"> <li>• Bypass valve (procedure 9), 248°F [120°C] or more</li> <li>• High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more</li> <li>• Low pressure sensor (procedure 11), 100°C or more</li> <li>• LEV (procedure 12), 248°F [120°C] or more</li> </ul> </li> </ol>
<p><b>12. Removing electronic expansion valve (LEV-A, LEV-B)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the service panel. (See Photo 1)</li> <li>(2) Remove the top panel. (See Photo 1)</li> <li>(3) Remove the cover panel (front). (Refer to procedure 8(5))</li> <li>(4) Remove the cover panel (rear) (Refer to procedure 8(6))</li> <li>(5) Remove the side panel (R). (Refer to procedure 8 (7))</li> <li>(6) Remove the electronic expansion valve coil. (See Photo 12)</li> <li>(7) Remove the electrical parts box. (See Photo 5)</li> <li>(8) Recover refrigerant.</li> <li>(9) Remove the welded part of electronic expansion valve.</li> </ol>	



OPERATING PROCEDURE	PHOTOS & ILLUSTRATION
<p><b>13. Removing the reactor (DCL)</b></p> <ol style="list-style-type: none"><li>(1) Remove the service panel. (See Photo 1)</li><li>(2) Remove the top panel. (See Photo 1)</li><li>(3) Remove the electrical parts box (See photo 5)</li><li>(4) Remove 4 screws for reactor (4 x 10) to remove the reactor. (See Figure 1)</li></ol>	<p><b>Figure 2</b></p>  <p>Electrical parts box</p> <p>Connectors of reactor</p> <p>Bottom plate of electrical parts box</p> <p>Reactor</p> <p>Screws for reactor</p>
<p><b>14. Removing the compressor (MC)</b></p> <ol style="list-style-type: none"><li>(1) Remove the service panel. (See Photo 1)</li><li>(2) Remove the top panel. (See Photo 1)</li><li>(3) Remove the electrical parts box. (See Photo 5)</li><li>(4) Remove the valve bed. (Refer to procedure 8 (4))</li><li>(5) Remove the cover panel (front). (Refer to procedure 8 (5))</li><li>(6) Remove the cover panel (rear) (Refer to procedure 8 (6))</li><li>(7) Remove the side panel (R). (Refer to procedure 8 (7))</li><li>(8) Remove front panel fixing screws, 5 (5x12) and 2 (4 x 10) and remove the front panel. (See Photo 4)</li><li>(9) Remove 3 separator fixing screws (4 x 10) and remove the separator. (See Figure 3)</li><li>(10) Recover refrigerant.</li><li>(11) Remove the 3 compressor fixing nuts using spanner or adjustable wrench.</li><li>(12) Remove the welded pipe of motor for compressor inlet and outlet and then remove the compressor.</li></ol> <p><b>Note:</b> Recover refrigerant without spreading it in the air.</p> <p><b>Figure 3</b></p>  <p>Separator fixing screws</p> <p>Separator fixing screw</p>	<p><b>Photo 13</b></p>  <p>Valve bed</p> <p>Valve bed fixing screw</p> <p>Valve bed fixing screws</p> <p>Right side panel</p> <p>Front cover panel fixing screws</p> <p>Rear cover panel fixing screws</p> <p><b>Photo 14</b></p>  <p>Compressor (MC)</p> <p>Separator</p> <p>Separator fixing screw</p> <p>Compressor fixing nut</p> <p>Accumulator</p> <p>Accumulator leg</p> <p>Accumulator leg fixing screws</p>





OPERATING PROCEDURE	PHOTOS
<p><b>15. Removing the accumulator</b></p> <ul style="list-style-type: none"><li>(1) Remove the service panel. (See Photo 1)</li><li>(2) Remove the top panel. (See Photo 1)</li><li>(3) Remove the electrical parts box. (See Photo 5)</li><li>(4) Remove the valve bed. (See procedure 8 (4))</li><li>(5) Remove the cover panel (front). (Refer to procedure 8(5))</li><li>(6) Remove the cover panel (rear) (Refer to procedure 8(6))</li><li>(7) Remove the side panel (R). (Refer to procedure 8 (7))</li><li>(8) Recover refrigerant.</li><li>(9) Remove 2 welded pipes of accumulator inlet and outlet.</li><li>(10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 16)</li></ul> <p><b>Note: Recover refrigerant without spreading it in the air.</b></p>	<p><b>Photo 15</b></p>  <p><b>Photo 16</b></p> 

# CITY MULTI

## mitsubishi electric corporation

HEAD OFFICE : TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO100-8310, JAPAN

---