

SANUVOX

Saber 24V Ultraviolet Lamp Magnet System

WARNING

Before installing or performing maintenance or service on the purifier, turn off unit and disconnect from power source. Electrical shock can cause injury or death. There may be more than one disconnect switch.

Never expose eyes or skin to ultraviolet light from any source. The Purifier **MUST** be **DISCONNECTED** from power source before performing maintenance or service. Personal injury may result.

Do not touch Lamp glass without gloves. Reduced performance of Lamp may result. Clean Lamp after handling.

The UV Lamp contains a small quantity of mercury. If a Lamp breaks, clean and dispose of with care.

Use only specified replacement Lamps with your Purifier. Use of an incorrect Lamp can result in damage to the Purifier and/or Lamp.

UV rays may destroy certain type of filters (polymer or plastic), please keep units away from shinning directly on plastic.

NOTICE

UV lamp can be disposed/recycle after use as for any other fluorescent bulb.

**Follow all safety codes.
Wear safety glasses and work gloves.**

PLEASE SAVE FOR YOUR RECORDS

Date Code#

Date Installed:

Installed By:

Installers Contact info.:


**SANUVOX 24V UV LAMP SYSTEM
INSTALLATION INSTRUCTIONS**

1. Disconnect power to the HVAC unit.
 2. Remove the ballast, brackets, UV Lamp retaining ring, view port, and UV Lamp from the package.
 3. Locate the ballast so that there is sufficient cable to attach to the UV Lamp when it is installed.
 4. The two piece Lamp bracket is used to hold the Lamp. Depending on the type of coil and the location of the UV Light on the coil will determine if one or both pieces of the bracket are used. The UV Lamp will be installed either with the Lamp on top of the coil or the lamp inside the coil.
 5. The Main Bracket can be mounted to the side of the coil allowing the UV Lamp to be inserted in-between or over the coil. Drill a 1" diameter hole in the sheet metal to allow the UV Lamp to pass and mount the Main Bracket to the side of the coil using the two included sheet metal screws. Once installed use the round metal Lamp Retaining Ring to lock the Lamp in place and tighten the two screws.
- Use of Magnetic Multi-Bracket: The Magnetic Multi-Bracket allows for various Lamp installations. Inspect the ideal location for the UV Lamp System and use the Main Bracket and Magnetic Multi-Bracket together if desired.*
6. Connect the plug onto the Lamp pins. The plug is designed so that it can only be installed one way. You may have to rotate the socket 90 degrees to line up the pins with the holes.
 7. Drill a 1/4 inch hole on the outside of the plenum on one side of the coil and install the view port. When the UV Lamp is operational, the glow of the Lamp will be visible through this port.
 8. Connect the black and white wires to the 24Volt terminals on the HVAC equipment.
 9. Reconnect power to the HVAC unit.

Ballast Operation, LED Notification & Reset

The 24V ballast is equipped with an LED status notifying the user of various system conditions. The LED notifications work as follows:

<p>System OK LED Solid</p> <p>Lamp > 8,700 hrs. (time to replace UV Lamp) LED FLASH 1 sec. / OFF 1 sec. Repeat.</p> <p>Lamp Fail LED FLASH 2X / pause 1 sec. Repeat.</p> <p>Ballast Fail LED FLASH 3X / pause 1 sec. Repeat.</p> <p>Low Voltage (under 18V)* LED FLASH 4X / pause 1 sec. Repeat.</p> <p>High Voltage (over 30V)* LED FLASH 5X / pause 1 sec. Repeat.</p> <p><i>*Connect w/ step-down transformer. Sold separately.</i></p>



RESET BUTTON: To reset an Error Code, press RESET button once. Following a Lamp replacement, press the RESET Button for 3 seconds to reset the 1 year timing function.

Maintenance
Disconnect all power before performing any maintenance or service. The Ultraviolet Lamp should be cleaned every two to three months. To clean, disconnect white socket from lamp. Loosen the 2 screws on the retainer ring. Turn retainer ring left. Pull out retainer ring and pull Lamp out. Wipe Lamp with a soft tissue and alcohol based solution. Reverse the above procedure to reinstall the Lamp. Lamps need periodic replacement to maintain design specifications. Replace lamps after 1 year of operation. Follow instructions for Ballast Operation (above) on how to Reset the Timer Feature. Contact a local dealer for replacement lamps.

Warranty
UV Lamp, 1 year warranty. Ballast, 5 year warranty.

