281-987-8400 • 281-987-9494 (fax) 1318 Buschong, Houston, TX 77039 www.mcdanielmetals.com

System Service Transition

COIL AND FURNACE MAINTENANCE MADE QUICKER AND EASIER





- Pre-assembled a perfect fit for most coil furnace matchups
- Compliments all system brands & models
- · Used in closet, up-flow, horizontal, attic & basement applications
- Quick & easy to install
- Available in R6 & R8 ductboard insulation
- Closet version (CL) door on front for AA, AB, AC, BB, BC & CC models
- Eliminates block-offs for maximum efficiency
- Easier maintenance protects system integrity & customer
- Test for and locate coil leaks in minutes
- No need to cut or remove panels or into coil box
- · User-friendly access door gasketed and insulated
- Drain pan accessory available
- Great upsell to clients that increases revenue for you

U.S. Pat. No 9267702 - U.S. Pat. No 10151507 / Canadian Pat. No 2865781 - Canadian Pat. No 2835898

SYSTEM SERVICE TRANSITION			
PART #	DESCRIPTION	PART #	DESCRIPTION
SST-AA-R6	14 X 21 - 14 1/4 X 21 A CAB FURNACE TO A CABINET COIL R-6 INSULATION	SST-AA-R8	14 X 21 - 14 1/4 X 21 A CAB FURNACE TO A CABINET COIL R-8 INSULATION
SST-AA-CL-R6	14 X 21 - 14 1/4 X 21 A CAB FURNACE TO A CABINET COIL R-6 INSULATION CLOSET	SST-AA-CL-R8	14 X 21 - 14 1/4 X 21 A CAB FURNACE TO A CABINET COIL R-8 INSULATION CLOSET
SST-AB-R6	14 X 21 - 17 3/4 X 21 A CAB FURNACE TO B CABINET COIL R-6 INSULATION	SST-AB-R8	14 X 21 - 17 3/4 X 21 A CAB FURNACE TO B CABINET COIL R-8 INSULATION
SST-AB-CL-R6	14 X 21 - 17 3/4 X 21 A CAB FURNACE TO B CABINET COIL R-6 INSULATION CLOSET	SST-AB-CL-R8	14 X 21 - 17 3/4 X 21 A CAB FURNACE TO B CABINET COIL R-8 INSULATION CLOSET
SST-AC-R6	14 X 21 - 21 1/4 X 21 A CAB FURNACE TO C CABINET COIL R-6 INSULATION	SST-AC-R8	14 X 21 - 21 1/4 X 21 A CAB FURNACE TO C CABINET COIL R-8 INSULATION
SST-AC-CL-R6	14 X 21 - 21 1/4 X 21 A CAB FURNACE TO C CABINET COIL R-6 INSULATION CLOSET	SST-AC-CL-R8	14 X 21 - 21 1/4 X 21 A CAB FURNACE TO C CABINET COIL R-8 INSULATION CLOSET
SST-BB-R6	17 1/2 X 21 - 17 3/4 X 21 B CAB FURNACE TO B CABINET COIL R-6 INSULATION	SST-BB-R8	17 1/2 X 21 - 17 3/4 X 21 B CAB FURNACE TO B CABINET COIL R-8 INSULATION
SST-BB-CL-R6	17 1/2 X 21 - 17 3/4 X 21 B CAB FURNACE TO B CABINET COIL R-6 INSULATION CLOSET	SST-BB-CL-R8	17 1/2 X 21 - 17 3/4 X 21 B CAB FURNACE TO B CABINET COIL R-8 INSULATION CLOSET
SST-BC-R6	17 1/2 X 21 - 21 1/4 X 21 B CAB FURNACE TO C CABINET COIL R-6 INSULATION	SST-BC-R8	17 1/2 X 21 - 21 1/4 X 21 B CAB FURNACE TO C CABINET COIL R-8 INSULATION
SST-BC-CL-R6	17 1/2 X 21 - 21 1/4 X 21 B CAB FURNACE TO C CABINET COIL R-6 INSULATION CLOSET	SST-BC-CL-R8	17 1/2 X 21 - 21 1/4 X 21 B CAB FURNACE TO C CABINET COIL R-8 INSULATION CLOSET
SST-BD-R6	17 1/2 X 21 - 24 3/4 X 21 B CAB FURNACE TO D CABINET COIL R-6 INSULATION	SST-BD-R8	17 1/2 X 21 - 24 3/4 X 21 B CAB FURNACE TO D CABINET COIL R-8 INSULATION
SST-BD-CL-R6	17 1/2 X 21 - 24 3/4 X 21 B CAB FURNACE TO D CABINET COIL R-6 INSULATION CLOSET	SST-BD-CL-R8	17 1/2 X 21 - 24 3/4 X 21 B CAB FURNACE TO D CABINET COIL R-8 INSULATION CLOSET
SST-CC-R6	21 X 21 - 21 1/4 X 21 C CAB FURNACE TO C CABINET COIL R-6 INSULATION	SST-CC-R8	21 X 21 - 21 1/4 X 21 C CAB FURNACE TO C CABINET COIL R-8 INSULATION
SST-CC-CL-R6	21 X 21 - 21 1/4 X 21 C CAB FURNACE TO C CABINET COIL R-6 INSULATION CLOSET	SST-CC-CL-R8	21 X 21 - 21 1/4 X 21 C CAB FURNACE TO C CABINET COIL R-8 INSULATION CLOSET
SST-CD-R6	21 X 21 - 24 3/4 X 21 C CAB FURNACE TO D CABINET COIL R-6 INSULATION	SST-CD-R8	21 X 21 - 24 3/4 X 21 C CAB FURNACE TO D CABINET COIL R-8 INSULATION
SST-CD-CL-R6	21 X 21 - 24 3/4 X 21 C CAB FURNACE TO D CABINET COIL R-6 INSULATION CLOSET	SST-CD-CL-R8	21 X 21 - 24 3/4 X 21 C CAB FURNACE TO D CABINET COIL R-8 INSULATION CLOSET
SST-DD-R6	24 1/2 X 21 - 24 3/4 X 21 D CAB FURNACE TO D CABINET COIL R-6 INSULATION	SST-DD-R8	24 1/2 X 21 - 24 3/4 X 21 D CAB FURNACE TO D CABINET COIL R-8 INSULATION
SST-DD-CL-R6	24 1/2 X 21 - 24 3/4 X 21 D CAB FURNACE TO D CABINET COIL R-6 INSULATION CLOSET		Rev. C 5/26/2020