



1. Attach Connection Arms (SW103) to the unit heater. Insert 3/8" Hex Tap Bolts through top of SW103; attach Flat Washers, Lock Washers and Nylon Insert Nuts.
2. Place Spreader Arm (SW102) over the 2 pressed-in bolts of the Connection Arms; attach. Place Flat Washer and Nut on pressed-in bolts. *Tighten and insert Safety Hitch Pins.*
3. Slide the Circular Adjustment Plate (SW100) over the 3/8" Swivel Bolt. SW100 should sit flat on Spreader Arm with flaps on each side of Arm. *Temporarily remove 1/4"-20 Hex Tap Bolts, Lock Washers and Nut from Circular Adjustment Plate (SW100).*
4. Slide Flush Mount Bar (SW101) over the 3/8" Swivel Bolt. FM Bar should sit flat on Adjustment Plate with flaps coming up on each side. Attach with hardware. Place Flat Washer on Swivel Bolt, followed by Lock Washer and Nut. *Once in place and tightened you must install Safety Hitch Pin.*
5. Install in place with hardware. Use one 3" Hex Lag Bolt, Split Lock Washer and Flat Washer on each side of FM Bar to attach securely. *Reinstall 1/4"-20 Hex Tap Bolts, Lock Washers and Nuts to the Circular Adj. Plate to lock in place.*

Note: Use second 3/8" Nut to lock first Nut on all Pembolts before installing Hitch Pins.

