

THE ADAPTER PLATE IS MEANT TO BE USED WITH THE FOLLOWING APRILAIRE PRODUCTS:

- Model 8400 Series Thermostat
- Model 8570 Thermostat
- Model 8900 Series Home Comfort Control™
- Model 8600 Series Thermostat
- Model 8800 Thermostat
- Model 8081 Remote Temperature Sensor
- Model 8082 Remote Humidity Sensor
- Model 76 Living Space Dehumidifier Control
- Model 65 Living Space Humidifier Control

INSTALLATION

STEP 1.

Identify mounting location for thermostat or sensor and install anchors if needed.

STEP 2.

Refer to the **Adapter Plate Hole Reference Chart** to identify which holes need to be drilled out from the adapter plate.

STEP 3.

Using a 1/8" diameter drill, drill out the slots/holes used for installation.

STEP 4.

Place the adapter plate with the arrow pointing up between the wall and thermostat base or sensor base, and fasten with screws.

ADAPTER PLATE HOLE REFERENCE CHART

Holes	Model
A-A	8081, 8082
B-B	8400 Series, 8570, 8600 Series, 8800, 8900 Series
C-C	8400 Series, 8570, 8600 Series, 8800, 8900 Series
D-D	76, 65
E-E	8870

